

## User Manual

# WR315GR-2C

Industrial Secure Cellular Router, 2C (Dual Core) Series

Jul.2022 V1.0  
HW 1.0



# WoMaster

## WR315GR -2C

Industrial Secured Cellular Router, 2C (Dual Core) Series

# User Manual

### Copyright Notice

© WoMaster. All rights reserved.

### About This Manual

This user manual is intended to guide a professional installer to install and to configure the WoMaster Industrial Secured and Rugged LTE Serial Router. It includes procedures to assist you in avoiding unforeseen problems.

#### **NOTE:**

Only qualified and trained personnel should be involved with installation, inspection, and repairs of this router.

### Disclaimer

WoMaster reserves the right to make changes to this Manual or to the product hardware at any time without notice. Information provided here is intended to be accurate and reliable. However, it might not cover all details and variations in the equipment and does not claim to provide for every possible contingency met in the process of installation, operation, or maintenance. Should further information be required or should particular problem arise which are not covered sufficiently for the user's purposes, the matter should be referred to WoMaster. Users must be aware that updates and amendments will be made from time to time to add new information and/or correct possible unintentional technical or typographical mistakes. It is the user's responsibility to determine whether there have been any such updates or amendments of the Manual. WoMaster assumes no responsibility for its use by the third parties.

### WoMaster Online Technical Services

At WoMaster, you can use the online service forms to request the support. The submitted forms are stored in server for WoMaster team member to assign tasks and monitor the status of your service. Please feel free to write to [help@womaster.eu](mailto:help@womaster.eu) if you encounter any problems.


# TABLE OF CONTENTS

COVER.....	1
TABLE OF CONTENTS .....	3
SAFETY PRECAUTION.....	6
1. INTRODUCTION.....	7
1.1 OVERVIEW .....	7
1.2 MAJOR FEATURES.....	9
2. HARDWARE INSTALLATION .....	10
2.1 HARDWARE DIMENSION .....	10
2.2 INSTALLATION.....	12
2.3 WIRING THE POWER INPUTS.....	12
2.4 WIRING THE ALARM RELAY OUTPUT (DO).....	13
2.5 CONNECTING THE GROUNDING SCREW .....	13
2.6 DIN RAIL MOUNTING .....	14
2.7 ANTENNA .....	15
2.8 SIM CARD INSTALLATION.....	16
2.10 WIRING THE DIGITAL INPUT (RESERVED).....	18
2.11 HARDWARE WATCHDOG .....	18
2.12 LED INDICATION.....	19
2.13 MICRO SD CARD .....	20
3. WEB MANAGEMENT CONFIGURATION .....	22
3.1 SYSTEM.....	27
3.1.1 INFORMATION .....	27
3.1.2 LOGIN SETTING .....	28
3.1.3 NETWORK SETTING .....	32
3.1.4 DATE AND TIME .....	35
3.1.5 DHCP SERVER.....	36
3.2 ETHERNET PORT .....	38
3.2.1 Port STATUS.....	38
3.2.2 Port SETTING.....	38
3.2.3 VLAN SETTINGS .....	39
3.2.4 TRAFFIC CONTROL.....	42
3.3 REDUNDANCY .....	42
3.3.1 VRRP .....	43
3.4 SERIAL (RESERVED).....	45

<b>3.5 CELLULAR</b> .....	<b>49</b>
<b>3.5.1 CELLULAR STATUS</b> .....	<b>49</b>
<b>3.5.2 CELLULAR SETTING</b> .....	<b>52</b>
<b>3.5.3 SIM SETTING</b> .....	<b>55</b>
<b>3.5.4 Cellular Diag</b> .....	<b>57</b>
<b>3.5.5 CELLULAR/WAN REDUNDANCY</b> .....	<b>57</b>
<b>3.5.6 DDNS SETTING</b> .....	<b>58</b>
<b>3.5.7 SMS REMOTE Control</b> .....	<b>59</b>
<b>3.5.8 SMS Alert</b> .....	<b>59</b>
<b>3.6 GPS</b> .....	<b>61</b>
<b>3.6.1 GPS STATUS</b> .....	<b>61</b>
<b>3.6.2 GPS SETTING</b> .....	<b>62</b>
<b>3.7 SECURITY</b> .....	<b>63</b>
<b>3.7.1 ACCESS CONTROL</b> .....	<b>63</b>
<b>3.7.2 OUTBOUND FIREWALL</b> .....	<b>67</b>
<b>3.7.3 NAT SETTING</b> .....	<b>71</b>
<b>3.7.4 OPEN VPN</b> .....	<b>74</b>
<b>3.7.5 IPSEC SETTING</b> .....	<b>80</b>
<b>3.7.6 GRE SETTING</b> .....	<b>82</b>
<b>3.7.7 L2TP SETTING</b> .....	<b>82</b>
<b>3.8 ROUTING</b> .....	<b>84</b>
<b>3.8.1 ROUTE</b> .....	<b>84</b>
<b>3.8.2 RIP</b> .....	<b>85</b>
<b>3.8.3 OSPF</b> .....	<b>87</b>
<b>3.9 WARNING</b> .....	<b>91</b>
<b>3.9.1 EMAIL ALERT</b> .....	<b>91</b>
<b>3.9.2 PING WATCHDOG</b> .....	<b>92</b>
<b>3.9.3 SYSLOG SETTING</b> .....	<b>92</b>
<b>3.9.4 RELAY OUTPUT</b> .....	<b>94</b>
<b>3.9.5 EVENT TYPE</b> .....	<b>94</b>
<b>3.9.6 SNMP</b> .....	<b>95</b>
<b>3.9.7 PERIODIC REBOOT</b> .....	<b>98</b>
<b>3.10 DIAGNOSTICS</b> .....	<b>99</b>
<b>3.10.1 EVENT LOGS</b> .....	<b>99</b>
<b>3.10.2 ARP TABLE</b> .....	<b>99</b>
<b>3.10.3 PING</b> .....	<b>101</b>
<b>3.10.4 TRACE ROUTE</b> .....	<b>101</b>
<b>3.10.5 NETWORK STATISTICS</b> .....	<b>102</b>
<b>3.10.6 DYING GASP</b> .....	<b>103</b>
<b>3.11 IoT</b> .....	<b>104</b>

3.11.1 AWS IoT .....	104
3.11.2 AZURE IoT .....	107
3.11.3 PRIVATE IoT .....	110
3.11.4 CoAP .....	114
3.11.4 Modbus Device.....	116
3.11.5 RMS/OTA .....	116
3.12 BACKUP AND RESTORE .....	123
3.13 FIRMWARE UPGRADE .....	124
3.14 RESET TO DEFAULTS .....	125
3.15 SAVE .....	125
3.16 LOGOUT .....	126
3.17 REBOOT .....	126
3.18 WOMASTER MIB.....	127
4. REVISION HISTORY .....	128
APPENDIX .....	129
ENTITY MIB (RFC4133).....	129
MIB-II (RFC1213).....	129

## SAFETY PRECAUTION

- **Statement regarding restricted access:**  The equipment is intended to be used in a restricted access location. Access should only be given to skilled person or instructed person who has been instructed in the operation of the equipment.




- **Only operate the device at the specified ambient temperature and humidity.**



- **High temperature warning:** When the router is operating, especially when the PoE power is supplied, it must be **Noted** that the temperature of the metal surface is very hot.
- **Power Specification:** Follow the power installing instruction of the user manual, it indicates the available input voltage range, V+/V- pin assignment, power consumption and other notice.



Connecting power with reverse polarity or using the wrong type of power supply may damage the equipment. Make sure that the power supply is connected correctly and of the recommended type.

- **Switch ON Notice:** Only switch on the supply voltage while the housing is closed, the input voltage is correct and the terminal blocks are wired correctly.
- **Wiring:** The connection cables used are permitted for the specified electronic voltage, current, wire diameter and temperature range. The quality of the RJ45 connector is also very important. In harsh environment, inferior quality RJ45 plug may also cause damage, short or even machine/PD damage.
- **Grounding:** The well grounding is important for EMC protection and make sure everything is done correctly before power on the system. **To avoid system damage, the equipment should be connected to ground.**
- **NOT allow to open the housing:** Only technicians authorized by the manufacturer are permitted to open the housing.
- **Mounting:**  The equipment is only suitable for mounting at height  $\leq 2\text{m}$ .
- **SIM:**  Ensure that the SIM card is installed correctly to avoid damage to the SIM card or the router.
- **SIM:**  **Caution:** Disconnect power before removing the SIM cover. The SIM cover must be mounted again before power is reapplied.
- **Be notice** the maximum power consumption of the product, it is NOT allowed to connect over the specification.

# 1. INTRODUCTION

## 1.1 OVERVIEW

New industrial high-performance router WR315GR-2C Series with dual-core 880MHz CPU has a M2 expansion socket for 5G NR Cellular as well as 4G LTE, 3G/2G networks. One Gigabit WAN port and four Gigabit LAN ports provide switch functions as well as WAN redundancy upon cellular networks. Security features such as Firewall, OpenVPN, are supported to safeguard cybersecurity. The embedded MQTTS, CoAP and RESTful API enables instant public cloud integration such as AWS or Azure. The ThingsMaster OTA can also be set up for an instant and secured access to receive data or manage devices remotely.

Model Name	Description
<b>WR315GR-M2-2C</b>	Industrial Secure Router, <b>Dual Core</b> , 5GbE, 1 Relay, 2SIM, 1x Expansion M2 socket
<b>WM-5G NR-M2-EU Kit</b>	Expansion 5G NR M2 Module Kit, 5G NR-EU Module, Heat Sink and Pad, 4xAntennas
<b>WM-5G NR-M2Q-GL Kit</b>	Expansion 5G NR M2 Module Kit, 5G NR-GL Module, Heat Sink and Pad, 4xAntennas
<b>WR315GR-2C-5GM2-EU (WR315GR-M2-2C+WM-5G NR-M2-EU Kit)</b>	Industrial Secure Router, <b>Dual Core</b> , 5GbE, 1 Relay, 2SIM, M2 socket with 5G NR-EU module kit (*choose one by region)
<b>WR315GR-2C-5GM2-GL (WR315GR-M2-2C+WM-5G NR-M2Q-GL Kit)</b>	Industrial Secure Router, <b>Dual Core</b> , 5GbE, 1 Relay, 2SIM, M2 socket with 5G NR-GL module kit (*choose one by region)
<b>WR315GR-2C-LTE6-(Region)</b>	Industrial Secure Router, <b>Dual Core</b> , 5GbE, 1 Relay, 2SIM, LTE6-(Region)
<b>8GSD-preinstall</b>	Industrial 8G SD card, pre-installed inside the housing *The micro SD socket is reserved inside the housing, SD card can be pre-installed according to the order. Please contact our sales.
	<b>5G NR/LTE Frequency/Bands:</b> *choose one by region: For other frequency bands not listed, please inquire with our sales. The datasheet list the available 5G NR/4G LTE module/region.
<b>Cellular Module</b>	<b>Frequency/Band Info</b>
<b>5G NR-EU</b>	<b>5G NR NSA/SA: 700M/3500MHz compliance</b> (n1/n3/n7/n8/n20/n28/n41/n77/n78 by module) <b>LTE FDD:</b> B1/B2/B3/B4/B5/B7/B8/B20/B28/B32 <b>LTE TDD:</b> B38/B40/B41/B42 <b>WCDMA:</b> B1/B3/B5/B6/B8 <b>GSM/GPRS/EDGE:</b> 900/1800/850/1900MHz <b>GNSS L1+L5</b> GPS/GLONASS/BeiDou(Compass)/Galileo

	*For other frequency bands not listed, please inquire with our sales.
<b>5G NR-GL (By Request)</b>	5G NR NSA: n41/n77/n78/n79 5G NR SA: n1/n2/n3/n5/n7/n8/n12/n20/n28/n38/n40/n41/n48*/n66/n71/n77/n78/n79 LTE FDD B1/B2/B3/B4/B5/B7/B8/B12/B13/B14/B17/B18/B19/B20/B25/B26/B28/B29/B30/B32/B66/B71 LTE TDD B34/B38/39/B40/B41/B42/B48 LTE LAA B46 WCDMA B1/B2/B3/B4/B5/B6/B8/B19 GNSS GP/GLONASS/BeiDou(Compass)/Galileo
<b>Band Information: LTE6-E (By Request)</b>	LTE Cat.6, M.2 form factor LTE-FDD: B1/B3/B5/B7/B8/B20/B28/B32* LTE-TDD: B38/B40/B41 WCDMA: B1/B3/B5/B8
<b>Band Information: LTE6-A (By Request)</b>	LTE Cat.6, M.2 form factor LTE-FDD: B2/B4/B5/B7/B12/B13/B25/B26/B29*/B30/B66 LTE-TDD: B40/B41 WCDMA: B2/B4/B5
<b>Band Information: LTE-EAU (By Request)</b>	LTE Cat.4, M.2 form factor LTE: FDD B1/B3/B7/B8/B20/B28 LTE: TDD B38/B40/B41 WCDMA: FDD B1/B8, GSM: B3/B8
© WoMaster Inc. All rights reserved. Specifications are subject to change without notice. Please ask our sales for the most up-to-date product information.	

## 1.2 MAJOR FEATURES

Below are the major features of WR315GR-2C Series:


- Dual Core High Speed Processor
- 5 x 100/1000MBase-T RJ45, Auto Negotiation, supports routing or bridging mode
- Extended M2 socket for 5G New Radio, SA+NSA, backward compatible support high speed 4G LTE
- 5G NR/4G/3G/2G full cellular network compatibility
- GNSS Support GPS/GLONASS/BDS/Galileo for location services
- Supports Dual SIM & Compliant with the eUICC international standard published by GSMA
- Reserved SD card inside the device which can store application programs or diagnostic log file.\*
- Supports Dying gasp alarm while power failure
- Supports Watchdog, Ping watchdog, Periodic/schedule Reboot, IPv4, SNMP v1/v2c/v3/Trap, Private MIB, DHCP server/client, DDNS, System Log, SD card configuration...etc.
- Cellular Configuration: Radio on/off, 4G LTE/3G HSPA Configuration, Dual SIM Standby setting, SIM Security, Connection Status, Cellular diagnostic, SMS Remote management
- Wireless redundancy: WAN/LTE Redundancy includes Eth-WAN Ping Tracking,
- Advanced Security system by OpenVPN, IPsec, L2TP, DMVPN, Firewall, IP/Port Filter, MAC ACL, NAT, DMZ, Port Forwarding between LAN/WAN, TLS, SSH/HTTPs, First login password management, MAC filtering, Ethernet port enable/disable...
- Event Notifications through E-mail, SNMP trap, SysLog and Digital/Relay Output
- Web, SNMP for network Management, Telnet CLI for diagnostic
- Steel Metal Housing and aluminum heat sinks inside for heat dissipation
- Wide range operating temperature -40~70°C
- Typical 24V (9-48V) power input
- IP30 ingress protection

## 2. HARDWARE INSTALLATION

This chapter introduces hardware and contains information on installation and configuration procedures.


### 2.1 HARDWARE DIMENSION

Dimensions of WR315G-2C: 50 x 151 x 120 (W x H x D) / without DIN Rail Clip



## Front Panel Layout

The front panel from WR315GR routers include 5 ports Giga Ethernet (100/1000 Base-T, RJ45), System + Ethernet + Radio LEDs, Reset button, 1 x 6-pin terminal block connector (4 pin for power inputs and 2 pin for Relay Output) and 1 chassis grounding screw on bottom side. There are 5 SMA antenna sockets, 5G NR connection usually requires 4 antennas, 4G LTE connection usually requires 2 antennas and one is reserved for GPS/GNSS. On the rear side of the device, there is DIN rail clip attached.



### Ethernet Port Map:

Port Map	Port Number	Bridge Mode	Router Mode(1xWAN)	Router Mode(2xWAN)
	Port 1	LAN	WAN 1	WAN 1
	Port 2		LAN	WAN 2
	Port 3			
	Port 4			
	Port 5		LAN	

Default port configuration is Bridge Mode, the default IP of the interface LAN ports: 192.168.10.1

Default IP of the interface WAN 1: 192.168.1.1

Default IP of the interface WAN 2: 192.168.2.1 (Note: Router 2xWAN mode may be applied to special firmware.)

**Antenna Map:**

	WR315GR-5GM2	WR315GR-LTE
Ant 1	5GNR-Main	LTE Main
Ant 2	5GNR-Main	LTE Div.
Ant 3	5GNR-Div.	-
Ant 4	5GNR-Div.	-
Ant 5	GNSS	By request

Note: Due to the different number of antennas used by 5GNR/4G LTE/3G/2G model, the feature of the antenna number may be different, the unused antenna positions will be covered by caps (even it has no functionality).

Note: If you only connect one antenna, please always connect the Ant 1. With one antenna attached, the connection speed, signal quality, and performance will be affected and cannot be guaranteed.

## 2.2 INSTALLATION

After unpack the box, follow the steps below in order to properly connect the device. For better signal/performance, put the device in a clearly visible spot, as obstacles such as walls and doors hinder the signal.

1. First, assemble router by attaching the necessary antennas and inserting the SIM card.
2. To power up router, please use the qualified power supply, connect the power input and reserved 24V@3A for the router.

## 2.3 WIRING THE POWER INPUTS

Power Input port in the router provides 2 sets of power input connections (P1 and P2) on the terminal block. On the picture below is the power connector.



### Wiring the Power Input

1. Insert the positive and negative wires into the V+ and V- contact on the terminal block connector.
2. Tighten the wire-clamp screws to prevent the power wires from being loosened.
3. Connect the power wires to suitable DC Switching type power supply. The typical input DC voltage is 24V, range of 9VDC to 48VDC.

**WARNING:** Turn off DC power input source before connecting the Power to the terminal block connectors, for safety purpose. Don not turn-on the source of DC power before all of the connections were well established.

## 2.4 WIRING THE ALARM RELAY OUTPUT (DO)


The relay output contacts are located on the front panel of the router. The relay output consists of the 2-pin terminal block connector that used to detect user-configured events. The two wires attached to the fault contacts form a close circuit when a user-configured event is triggered. If a user-configured event does not occur, the fault circuit remains open. The fault conditions such as power failure, Ethernet port link break or other pre-defined events which can be configured in the device. Screw the DO wire tightly after digital output wire is connected.



**NOTE:** The relay contact only supports 1 A current, DC 24V. Do not apply voltage and current higher than the specifications.


## 2.5 CONNECTING THE GROUNDING SCREW

Grounding screw is located on the bottom side of the router. Grounding Screw helps limit the effects of noise due to electromagnetic interference (EMI) such as lightning or surge protection. Run the ground connection from the ground screw to the grounding surface prior to connecting devices. And tighten and wire to chassis grounding for better durability.



## 2.6 DIN RAIL MOUNTING

The EN50022 DIN-Rail plate should be already attached to the back panel of the device screwed tightly. If user needs to reattach the DIN-Rail attachment plate to the device, make sure the plate is situated towards the top, as shown by the following figures.




To mount the router on DIN Rail track, do the following instruction:

1. Insert the top side of DIN Rail track into the slot of DIN Rail clip.
2. Lightly clip the bottom of DIN-Rail to the track and make sure it attached well.
3. To remove the device from the track, reverse the steps.


## 2.7 ANTENNA

WR315GR are supported with up to 5 antenna sockets, where 2G/3G/4G LTE/5G NR and GPS/GNSS antennas are supported. All of the antennas are connected to the router by screwing all the antennas to the SMA connector on the front panel of the router.

### 5G NR Antenna

	<b>Frequency</b>	690 ~ 960 MHz / 1710 ~ 2700 MHz / 3200~3800MHz/ 4400~5900MHz
	<b>V.S.W.R</b>	<= 2.5
	<b>Peak Gain (major)</b>	Up to 5.7dBi 690MHz: 0.73dBi, 960MHz: 2.98dBi, 1710MHz: 3.11dBi, 1800MHz: 2.54dBi, 1900MHz: 2.42dBi, 3300MHz: 5.6dBi, 3500MHz: 4.12dBi, 3800MHz: 4.92dBi, 4000MHz: 3.75dBi, 5000MHz: 4.18dBi
	<b>Directional</b>	Omni-directional
	<b>Impedance</b>	50 Ohm
	<b>Connector Type</b>	SMA Male
	<b>Dimension</b>	222xΦ13 mm, 27mm width
	<b>Operational Temperature</b>	- 10 °C ~ +70 °C

### 4G LTE Antenna

	<b>Frequency</b>	690 ~ 960 MHz / 1710 ~ 2700 MHz
	<b>V.S.W.R</b>	<= 3.0
	<b>Radiation</b>	Omni
	<b>Peak Gain</b>	3.15dBi 690MHz: 1.36dBi, 960MHz: 1.37dBi, 1710MHz: 3.12dBi, 1800MHz: 1.29dBi, 1900MHz: 2.63dBi, 2100MHz: 1.47dBi, 2170MHz: 1.14dBi, 2500MHz: 3.15dBi, 2600MHz: 2.46dBi, 2700MHz: 1.89dBi
	<b>Directional</b>	Omni-directional
	<b>Impedance</b>	50 Ohm
	<b>Connector</b>	SMA Male
	<b>Dimension</b>	200xΦ13 mm
	<b>Operational Temperature</b>	- 20 °C ~ +65 °C

**NOTE:** Please refer to device stick for antenna combination of different models


## 2.8 SIM CARD INSTALLATION

### SIM Card Slot

The SIM Card Slot is used to insert the cellular card. The WR315GR-2C Series can support Dual SIM redundant.



SIM indication on front panel



To install/uninstall SIM card:

1. Use screwdriver to loosen screws and remove SIM cover.
2. Insert a paper clip or a SIM-eject tool into the hole beside the SIM socket. Push in towards the device, but don't force it. The SIM 1 is the primary SIM in the default configuration.
3. (When install) Draw out SIM tray and install SIM card on top side of tray  
(When uninstall) Draw out SIM tray and uninstall SIM card

**WARNING:** Be careful when install the SIM Card, wrong installation procedure will cause damage.  
Please follow the mechanical print out to install the SIM Card.


4. Insert tray back to SIM socket and reattach SIM cover.

To Configure SIM Card Setting, check the Chapter 3.5 Cellular settings in user manual.

If you inserted one SIM, the default primary SIM is SIM 1.

If you inserted two SIM for Cellular Redundant, you can configure which is primary and active Cellular Redundant in web GUI.


You can check and configure the APN Name, PIN number of your SIM setting in Cellular/SIM setting page. If your carrier provider has their preferred APN Name, please change it in Cellular Setting, otherwise, you may not available to connect correctly.



The screenshot shows the Cellular Setting web GUI. The 'Cellular Setting' tab is active, and the 'Cellular/ETH-WAN Redundancy' is set to 'Disable'. Under 'Cellular1 Profile', the 'Cellular Redundant' option is set to 'Enable'. The 'Redundant Parameters' section shows 'Period' set to '30 sec' and 'Number of Retries' set to '3'. The 'SIM Selection' section shows 'SIM1' selected. The 'SIM1 Settings' and 'SIM2 Settings' sections are visible below, with 'SIM1 APN' set to 'internet'. The 'SIM Setting' panel on the right shows 'SIM Status' as 'SIM OK', 'Number of Retries Remain' as '2', and 'SIM1 PIN' as an empty field. The 'Remember PIN' option is selected, and 'PIN Protection' is set to 'Disable PIN'.

## 2.9 WIRING THE DIGITAL OUTPUT (Reserved)

The digital output of the terminal block is used to detect user-configured events. The two wires attached to the fault contacts form a close circuit when a user-configured event is triggered. If a user-configured event does not occur, the fault circuit remains opened.



### **Wiring the Digital Output**


1. Insert the positive and negative wires into the DO+ and DO- contact on the terminal block connector.
2. Tighten the wire-clamp screws to prevent the wires from being loosened.

**WARNING:** Please confirm the wire installation according to the above steps, otherwise it would not work properly. It only supports 0.1 A current, DC 30V. Do not apply voltage and current higher than the specifications.

**Note:** WR315-2C supports Relay Output. Not every model of WR315 series supports Digital Input and Digital Output. The feature is reserved for the WR315GR-2C with Digital Output model only.

## 2.10 WIRING THE DIGITAL INPUT (Reserved)

To wire the DI on the Terminal block, use screwdriver to loosen screws, insert the positive and negative wires into the DI 1/2/3 and COM contact and then tighten screws after the DI wire is connected.



### Wiring the Digital Input

1. Insert the positive and negative wires into the DI 1/2/3 and COM contact on the terminal block connector.
2. Tighten the wire-clamp screws to prevent the wires from being loosened.
3. Input signal voltages range from 0 volts to 1 volts for a “**low**” logic state and 2 volts to 30 volts for a “**high**” logic state.

**WARNING:** Please confirm the wire installation according to the above steps, otherwise it would not work properly.

**Note:** Not every model of WR315-2C series supports Digital Input and Digital Output. The feature is reserved for the WR315GR-2C with Digital Input model only.

## 2.11 HARDWARE WATCHDOG

The device provides a hardware watchdog mechanism for critical event, such as system reboot is to cut the power of the whole device to get a clean restart of all components.

The device also provides a “dying gasp” alert. The router can generate syslog event or SNMP trap to target server when the router loses power.


Some of the features are also available as watchdog. Refer to:

3.10.2 Ping Watchdog

3.10.7 Periodic Reboot

3.5.7 SMS remote control reboot.

## 2.12 LED Indication



### System & Interface LED:

LED	Status	Description
PWR (Power)	Green On	DC-IN Power is On
	Off	No Power in DC-IN
SYS (System)	Green On	Ready
	Green Blinking	Firmware updating
	Off	Not Ready
DO (Relay)	Red On	Any failures SW control
	Off	No failure occurs
Giga Ethernet Port 1-5	Green On	Links established
	Green Blinking	Packets transmitting/receiving
	Off	Link is inactive

### Radio LED


LED	Status	Description	
WR315GR-2C	Ra	Green On	SIM detected
		Off	SIM not insert
	Rb	Green On	Cellular Signal Good
		Green Blinking	Cellular Signal Medium
		Off	Cellular Signal Low
	Rc	Green On	Connected
		Off	Not Connected
	Rd	Module Diagnostic	Depends on module, check detail with our engineer.

## 2.13 Micro SD Card

The SD Card Slot is reserved inside the housing, it is used for field diagnostic data logging/option for storage per demand. To insert SD card after purchased, you need to open the housing, insert it correctly and carefully. For safety and warranty concern, we prefer to insert SD card during production. Please contact our sales while you need to use SD feature, we can do this according to the order.

Following is the steps to insert SD card.

1. Shut down the power.
2. Please wear anti-static gloves when disassembling the housing.
3. Unlock the screws to open the side panel. There are several heat sinks pasted on the side panel, please keep them clean and put them back when re-assembling.



4. Prepare the SD card. Please always use industrial grade SD card, it has better lifecycle and wider range of the operating temperature.
5. Follow the steps below to place the SD card into the socket.
  - 5.1 Find the SD socket and check the Open/Lock direction.
  - 5.2 Open the SD socket.
  - 5.3 Put the SD into the socket.
  - 5.4 Lock the SD socket.


The figure below is an example of placing and SD card.

1. Find the socket and check the Open/Lock direction.

2. Open the SD socket.

3. Put the SD into the socket.

4. Lock the SD socket.



6. After placing the SD card, lock the side panel and put the heat sink back to the correct position.

### 3. WEB MANAGEMENT CONFIGURATION


---

To access the management interface, WoMaster router has two ways access mode through a network; they are web management and telnet management. Web interface management is the most common way and the easiest way to manage a network, through web interface management, a router interface offering status information and a subset of device commands through a standard web browser. If the network is down, another alternative to access the management interface can be used. The alternative way is by using telnet management which is offer configuration way through CLI Interface. This manual describes the procedures for Web Interface and how to configure and monitor the managed router only.

#### **PREPARATION FOR WEB INTERFACE MANAGEMENT**

WoMaster provides Web interface management that allows user through standard web-browser such as Microsoft Internet Explorer, or Mozilla, or Google Chrome, to access and configure the router management on the network.

1. Plug the DC power to the router and connect router to computer.
2. Make sure that the router default IP address is **192.168.10.1**.
3. Check that PC has an IP address on the same subnet as the router. For example, the PC and the router are on the same subnet if they both have addresses that start 192.168.10.x (Ex: **192.168.10.2**). The subnet mask is 255.255.255.0.
4. Open command prompt and ping **192.168.10.1** to verify that the router is reachable.
5. Launch the web browser (Internet Explorer or Mozilla Firefox or Google Chrome) on the PC.
6. Type <http://192.168.10.1> (or the IP address of the router). And then press **Enter** and the login page will appear.
7. Type user name and the password. In earlier firmware, the default user name: **admin** and password: **admin**. Then click **Login**. In latest firmware, the system will ask you **enter the new password in your first login**. Please follow the prompt to enter new password.



8. In first Login, then user will be asked to change the default password with a new password.  
Enter new password and Submit to apply the change.

**Please change the password!**

User Name

New Password

Confirm Password

**Change settings successfully!**

Then re-login with the new password.

**Note:** User must finish changing the password in web GUI before login with CLI.

Web GUI Console Example 1: System Information

Home > System > Information

Information | Login Settings | Network Settings | Date and Time | DHCP Server

**WR312-WLAN+LTE-E Industrial Secure Cellular Router** ← The model name.

System Name: router

System Description: Industrial Secure Cellular Router

Software Version: beta-02241735

MAC Address: 94:66:e7:9f:00:02

IP Address: 192.168.10.1

Subnet Mask: 255.255.255.0

Gateway IP Address: 0.0.0.0

SD Card Status: Not Inserted

Save Logout Reboot

System  
 Ethernet Port  
 Serial  
 Cellular  
 GPS  
 Wireless LAN  
 Security  
 Routing  
 Warning  
 Diagnostics  
 IoT  
 Backup/Restore  
 Firmware Upgrade  
 Reset to Default

Main software feature set.

Secondary software feature set

Configuration page of the software features.  
 Ex: Information of the System

Slide bar

Permanently save the submitted setting.

Logout the web GUI.

Reboot the router

Web GUI Console Example 2: Network Setting Configuration. Click “Submit” to apply the change. Click “Save” to save the new setting permanently, the setting will be remained after reboot.

Home > System > Network Settings

Information | Login Settings | Network Settings | Date and Time | DHCP Server

IP Address: 192.168.10.1

Subnet Mask: 255.255.255.0

Gateway Ip Address: 0.0.0.0

DNS 1: 8.8.8.8

DNS 2: 0.0.0.0

ARP Settings

Proxy ARP  Enable

Submit Cancel

Save Logout Reboot

System  
 Ethernet Port  
 Serial  
 Cellular  
 GPS  
 Wireless LAN  
 Security  
 Routing  
 Warning  
 Diagnostics  
 IoT  
 Backup/Restore  
 Firmware Upgrade  
 Reset to Default

Main software feature set.

Secondary software feature set

Configuration page of the software features.  
 Ex: Network Setting Configuration

Slide bar

Permanently save the submitted setting.

Logout the web GUI.

Reboot the router

Submit to apply the change.  
 (Click “Save” to permanently save the new setting.)

After click **“Save”**, click **“Yes”** to save the submitted changes. Please wait around 5-10 seconds, the system will then save the new settings to flash permanently. Do not power off or reboot the system during the 5-10 seconds.



**Save**

Do you want to save all submitted changes?



In this Web management for Featured Configuration, user will see all of WoMaster Cellular Router's various configuration menus at the left side from the interface. Through this web management interface, user can configure, monitoring, and set the administration functions. The whole information used web management interface to introduce the featured functions. User can use all of the standard web-browser to configure and access the router on the network.

Following topics are covered in this chapter:

- 3.1 System
- 3.2 Ethernet Port
- 3.3 Redundancy
- 3.4 Serial
- 3.5 Cellular
- 3.6 GPS
- 3.7 Wireless LAN
- 3.8 Security
- 3.9 Routing
- 3.10 Warning
- 3.11 Diagnostics
- 3.12 IoT
- 3.13 Backup and Restore
- 3.14 Firmware Upgrade
- 3.15 Reset to Defaults
- 3.16 Save
- 3.17 Logout
- 3.18 Reboot
- 3.19 WoMaster MIB

## 3.1 SYSTEM

When the user login to the router, user will see the system section appear. This section provides all the basic setting and information or common setting from the router that can be configured by the administrator.

Following topics are included:

3.1.1 Information

3.1.2 Login Setting

3.1.3 Network Settings

3.1.4 Date and Time

3.1.5 DHCP Server

### 3.1.1 INFORMATION

Information section, this section shows the basic information from the router to make it easier to identify different router that is connected to User network and also it shows the Cellular Status and LAN Settings information. The figure below shows the interface of the Information section.

**WR315GR-2C-5GM2 Industrial Secure Serial Router, Dual Core, 5GbE, 1 Relay, 2SIM, 5GNR**

<b>System Name</b>	<input type="text" value="router"/>
<b>System Description</b>	Industrial Secure Serial Router, Dual Core, 5GbE, 1 Relay, 2SIM, 5GNR
<b>Software Version</b>	0.1
<b>MAC Address</b>	00:0c:43:28:80:10
<b>IP Address</b>	192.168.10.1
<b>Subnet Mask</b>	255.255.255.0
<b>Gateway IP Address</b>	0.0.0.0
<b>System SN</b>	
<b>Uptime</b>	9m 55s
<b>SD Card Status</b>	Not Inserted

The description of the Information's interface is as below:

TERMS	DESCRIPTION
<b>System Name</b>	<b>Default: router</b> Set up a name to the device.
<b>System Description</b>	Display the name of the product.
<b>Software Version</b>	Display the firmware latest version that installed in the device.
<b>MAC Address</b>	Display the hardware's MAC address that assigned by the manufacturer.
<b>IP Address</b>	Display the IP Address of the device
<b>Subnet Mask</b>	Display the subnet mask of the device
<b>Gateway IP Address</b>	Display the IP address of the default gateway
<b>System SN</b>	Display the serial number of the device
<b>Uptime</b>	Display the uptime of the device

<b>SD Card Status</b>	Display the SD Card status when the SD Card is inserted or not inserted. *Reserved inside the box for system log/diagnostic, please check with our engineer whether your device's software support this feature or not first.
-----------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### 3.1.2 LOGIN SETTING

WoMaster' router supports Login Setting that has several authentication methods. It is supported with TACACS+, Radius, and Multi-User Authentication. This Login Setting consists of two level, admin and guest. Where the admin level, it has the privilege to read and write and for the guest level the privilege is read only. Below is the **Login Setting** section for **admin level**.

**User Name:**

**New Password:**

**Confirm Password:**

With the Name default setting is **admin** and the authority allow user to configure all of configuration parameters. The Login Setting interface describes how to configure the system username and password for the web management login. To change the Name and Password, user just needs to input a new Name and New Password then confirm the new password in this section. Try to re-login with the new User Name and Password.

Below is the interface for **guest level**.

**Guest Name**

**New Password**

**Confirm Password:**

With the Name default setting is **guest** and the authority allow user to read only all of configuration parameters.

**NOTE:** For security consideration, please change the password after first log in.

When user try to change the configuration, message will appear if user is not permitted to configure the configuration. Below is the interface.

**Your permission is not enough to perform the action!**

The description of the Login Setting interface is as below:

TERMS	DESCRIPTION
User Name/ Guest Name	<b>Default: admin/guest</b> Key in new username here.
New Password	Key in new password here.
Confirm Password	Re-type the new password again to confirm it.

After finishing configure the Username and Password, click on **Submit** to apply the configuration. Don't forget to **Save** the configuration.

### User Authentication Mode

The user authentication can be performed locally and remotely using Radius or TACACS+ authentication server. It has 5 authentication modes which are Local, RADIUS, RADIUS->Local, TACPLUS, and TACPLUS->Local. The default authentication method is Local method, where it works for multi user authentication that has been explained above.

### **RADIUS**

The Remote Authentication Dial-In User Service (RADIUS) protocol was developed by Livingston Enterprises as an access server authentication and accounting protocol. The RADIUS server can support a variety of methods to authenticate a user. When it is provided with the username and original password given by the user, it can support PPP, PAP or CHAP, UNIX login, and other authentication mechanisms.

Below is the RADIUS and RADIUS to Local authentication mode interface where the device takes a role as a RADIUS client that needs to authenticate with the RADIUS server database. For the RADIUS to Local mode, the authentication will try remote authentication first, falling back to local authentication mode if remote mode fails.

**Authentication Mode**

Authentication Mode:

**RADIUS Server**

RADIUS Server IP:

Shared Key:

Server Port:

**Secondary RADIUS Server**

RADIUS Server IP:

Shared Key:

Server Port:

How to set up a RADIUS server:

- a. Enter the IP address of the RADIUS server in **Server IP Address**
- b. Enter the **Shared Secret** of the RADIUS server
- c. Enter the **Server port** if necessary, by default RADIUS server listens to port 1812

- d. Click **Submit**

The description of the RADIUS Authentication interface is as below:

TERMS	DESCRIPTION
<b>RADIUS Server IP</b>	Radius Server IP Address
<b>Shared Key</b>	Shared key are used to verify that RADIUS messages, with the exception of the Access-Request message, are sent by a RADIUS-enabled device that is configured with the same shared key. Shared key also verify that the RADIUS message has not been modified in transit (message integrity).
<b>Server Port</b>	Set communication port of an external RADIUS server as the authentication database. The general value is 1812

### TACACS+

The Terminal Access Controller Access Control System (TACACS+) security protocol is a recent protocol developed by Cisco. It provides detailed accounting information and flexible administrative control over the authentication and authorization processes. TACACS+ allows for a single access control server (the TACACS+ daemon) to provide authentication, authorization, and accounting services independently. Below is the interface for TACPLUS and TACPLUS to Local authentication mode. For the TACPLUS to Local mode, the authentication will try remote authentication first, falling back to local authentication mode if remote mode fails or cannot be reached.

**Authentication Mode**

Authentication Mode:

**TACPLUS Authentication Setting**

Authentication Type:

Authentication Timeout:

**TACPLUS Server**

TACPLUS Server IP:

Shared Key:

Server Port:

**Secondary TACPLUS Server**

TACPLUS Server IP:

Shared Key:

Server Port:

How to set up a TACACS+ server:

- Select the **Authentication Type**.
- Enter the **Authentication Timeout** in seconds.
- Enter the IP address of the TACACS+ server in **Server IP Address**.
- Enter the **Shared Secret** of the TACACS+ server.

- e. Enter the **Server port** if necessary, by default TACACS+ server listens to port 49.
- f. Click **Submit**


The description of the TACACS+ Authentication interface is as below:

TERMS	DESCRIPTION
<b>Authentication Type</b>	<b>Default: ASCII</b> Select the authentication type to authenticate to the server.
<b>Authentication Timeout</b>	<b>Default: 5</b> The maximum number of seconds allowed establishing a TCP connection between the device and the TACACS+ server. If the server cannot be reached within the limit time, and it will directly change to Local. This configuration is applied to TACPLUS->Local mode only.
<b>TACPLUS Server IP</b>	TACACS+ Server IP Address
<b>Shared Key</b>	Specifies the shared key for TACACS+ communications between the device and the TACACS+ server. The shared key must match the encryption used on the TACACS+ server.
<b>Server Port</b>	Set communication port of an external TACACS+ server as the authentication database. The general value is 49

### 3.1.3 NETWORK SETTING

The Network Setting section allows users to configure both IPv4 values for management access over the network. Below is the Ethernet port map of the WR315GR-2C router. The router can be configured as Bridge mode or Router mode. In Router mode, the router can support up to 2 WAN interfaces.

#### Ethernet Port Map:

Port Map	Port Number	Bridge Mode	Router Mode(1xWAN)	Router Mode(2xWAN)
	Port 1	LAN	WAN 1(eth1)	WAN 1 (eth1)
	Port 2		LAN	WAN 2 (eth2)
	Port 3			LAN
	Port 4			
	Port 5			

Default port configuration is Bridge Mode, the default IP of the interface LAN ports: 192.168.10.1

Default IP of the interface WAN 1(eth1): 192.168.1.1

Default IP of the interface WAN 2(eth2): 192.168.2.1 (Note: 2xWAN mode may be applied to special firmware.)

#### Bridge Mode

Below is the Network Setting interface for **Bridge Mode**.

**Network Settings**

Network Mode Bridge

Submit Cancel

**LAN Settings**

Interface	Type	IP Address	Subnet Mask	Default Gateway
<input type="checkbox"/> vlan1	<span style="border: 1px solid gray; padding: 2px;">Static IP</span>	<input style="width: 100px;" type="text" value="192.168.10.1"/>	<input style="width: 100px;" type="text" value="255.255.255.0"/>	<input style="width: 100px;" type="text" value="0.0.0.0"/>

Submit Cancel

**DNS Settings**

DNS 1

DNS 2

Submit Cancel

The description of the columns is as below:

TERMS	DESCRIPTION
<b>LAN Access Type</b>	User can select to DHCP or Static IP to activate the function. <b>DHCP:</b> Select DHCP to activate DHCP Client Function, no need to assign IP Address and received IP Address from DHCP Server. <b>Static IP:</b> Select Static IP to configure the IP configuration manually
<b>IP Address</b>	<b>Default: 192.168.10.1</b> Set up the IP address reserved by User network for User device. If DHCP

	Client function is enabled, no need to assign an IP address to device as it will be overwritten by DHCP server and shown here.
<b>Subnet Mask</b>	<b>Default: 255.255.255.0</b> Assign the subnet mask for the IP address here. If DHCP Client function is enabled, no needs to assign the subnet mask.
<b>Default Gateway</b>	<b>Default: 0.0.0.0.</b> Assign the gateway for the device here.
<b>DNS 1</b>	Specifies the IP address of the DNS server 1 that used in user network.
<b>DNS 2</b>	Specifies the IP address of the DNS server 2 that used in user network.

## Router Mode

And below is the Network Setting interface for the **Router Mode** where it supports with the WAN port on port 1(eth1) and WAN 2 on port 2(eth2). User can configure the WAN Settings and LAN settings.

### Network Settings

**Network Mode** Router

#### WAN Settings

Interface	Type	IP Address	Subnet Mask	Default Gateway
eth1	Static IP	192.168.1.1	255.255.255.0	0.0.0.0
eth2	Disable	192.168.2.1	255.255.255.0	0.0.0.0

#### LAN Settings

Interface	Type	IP Address	Subnet Mask	Default Gateway
<input type="checkbox"/> vlan1	Static IP	192.168.10.1	255.255.255.0	0.0.0.0

#### DNS Settings

**DNS 1**

**DNS 2**

The IPv4 Configuration includes the router's IP address and subnet mask, as well as the IP address of the default gateway. In addition, input cells are provided for the IP addresses of a 1st and 2nd DNS server.

It is also supported DNS Proxy which uses the Domain Name Relay Daemon (DNRD). It takes DNS queries from hosts, and forwards them to the "real" DNS server. It takes DNS replies from the DNS server, and forwards them to the client. It is meant to be used for home networks that can connect to the internet using one of several ISP's. DNRD is

pretty simple. Configure the managed router's IP settings. The figure above shows the user interface of IPv4 Configuration. The description of the columns is as below:

TERMS	DESCRIPTION
<b>WAN Access Type</b>	User can select to DHCP Client or Static IP to activate the function. <b>DHCP Client:</b> Select DCHP Client to activate DHCP Client Function, no need to assign IP Address and received IP Address from DHCP Server. <b>Static IP:</b> Select Static IP to configure the IP configuration manually <b>Disable:</b> Select disable to indicate that port 2 is not WAN interface.
<b>IP Address</b>	<b>Default: 192.168.1.1</b> Set up the IP address reserved by User network for User device. If DHCP Client function is enabled, no need to assign an IP address to device as it will be overwritten by DHCP server and shown here.
<b>Subnet Mask</b>	<b>Default: 255.255.255.0</b> Assign the subnet mask for the IP address here. If DHCP Client function is enabled, no needs to assign the subnet mask.
<b>Default Gateway</b>	<b>Default: 0.0.0.0.</b> Assign the gateway for the device here.
<b>DNS 1</b>	Specifies the IP address of the DNS server 1 that used in user network.
<b>DNS 2</b>	Specifies the IP address of the DNS server 2 that used in user network.

### Proxy ARP

Proxy ARP is a technique in which one host, usually a router answers ARP requests intended for another node located on another network. The router or "faking" its identity or pretends to be the target of the ARP requests by sending ARP responses that associate its own MAC address with the real (destination) node's IP address. The router acts as a proxy and takes responsibility for routing packets to the real destination. Proxy ARP can help machines on a subnet reach remote subnets without the need to configure routing or a default gateway.

When Proxy ARP is enabled, if the router receives an ARP request for which it has a route to the target (destination) IP address, the router responds by sending a Proxy ARP reply packet containing its own MAC address. The host that sent the ARP request then sends its packets to the router, which forwards them to the intended host.

Below is the interface.

Check the box to enable the function of Proxy ARP.

### 3.1.4 DATE AND TIME

The WoMaster router has a time calibration function based on information from an NTP server or user specified time and date, allowing functions such as automatic warning emails to include a time and date stamp.

**Date and Time**

**Current Time** Yr  Mon  Day  Hr  Mn  Sec

**Time Zone**

**NTP**  Enable NTP client update

**NTP server**

**Manual IP**

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Current Time</b>	User can configure time by input it manually. User also can click the <b>Get PC Time or Get Time from Cellular</b> to get the time setting. Get PC Time: get the time the PC Get Time from Cellular: get the time from the cellular network.
<b>Time Zone</b>	Choose the Time Zone section to adjust the time zone based on the user area.
<b>NTP</b>	<b>Enable NTP Client update</b> by checking this box. Select the time server from the <b>NTP Server</b> dropdown list or select <b>Manual IP</b> to manually input the IP address of available time server. <b>*Make sure that the device also has the internet connection.</b>

After finished configuring, click on **Submit** to activate the configuration.

### 3.1.5 DHCP SERVER

#### DHCP Server Setting

WoMaster router has DHCP Server Function that will provide a new IP address to DHCP Client. After enabling DHCP Server function, set up the Network IP address for the DHCP server IP address, Subnet Mask, Default Gateway address and Lease Time for client. Below is the DHCP Server Setting interface

**DHCP Server**

**DHCP Settings** Enable ▾

**IP Address Start**

**IP Address End**

**Subnet Mask**

**Gateway**

**WINS1**

**WINS2**

**Primary DNS Server**

**Secondary DNS Server**

**Lease Time**  (15-44640 minutes)

**Enable DHCP Relay**

**DHCP Server IP**

The description of the columns is as below:

TERMS	DESCRIPTION
<b>DHCP Setting</b>	Select to <b>Enable</b> or <b>Disable</b> to activate and deactivate DHCP Server function.
<b>IP Address Start</b>	Assign the IP Address Start range.
<b>IP Address End</b>	Assign the IP Address End range.
<b>Subnet Mask</b>	<b>Default: 255.255.255.0</b> Assign the subnet mask for the IP address here for DHCP Server.
<b>Gateway</b>	Assign the gateway for the router here for DHCP Server.
<b>WIN S1</b>	Enter WINS Server 1 IP address
<b>WIN S2</b>	Enter WINS Server 2 IP address
<b>Primary DNS Server</b>	Enter Primary DNS Server that used in user network.
<b>Secondary DNS Server</b>	Enter Secondary DNS Server that used in user network.
<b>Lease Time</b>	<b>Default: 1440</b> The maximum length of time for the IP address lease. Enter the Lease time in minutes. (Lease Time range: 15-44640 minutes)
<b>Enable DHCP Relay</b>	Select the checkbox to Enable the DHCP Relay feature.
<b>DHCP Server IP</b>	Type the DHCP Relay Server IP.

The DHCP Server will automatically assign an IP address to the computers on the LAN/private network. Be sure to set user computers to be DHCP clients by setting their TCP/IP settings to “Obtain an IP Address Automatically.” When user turns the computers on, they will automatically load the proper TCP/IP settings provided by the router. If User manually assigns IP addresses to User computers or devices, make sure the IP addresses are outside of this range or User may have an IP conflict. After finished configuring, click on **Submit** to activate the configuration.

**DHCP Leased Entries**

The figure below shows the **DHCP Leased Entries**. It will show the MAC and IP address that was assigned by router. Click the **Reload** button to refresh the list.

**DHCP Leased Entries**

IP Address	MAC Address	Time to expire(s)
192.168.10.101	94:66:e7:ff:11:92	86379

[Reload](#)

The description of the columns is as below:

TERMS	DESCRIPTION
<b>IP Address</b>	IP address that was assigned by router.
<b>MAC Address</b>	The MAC Address of the network interface that was used to acquire the lease.
<b>Time to expire(s)</b>	Remains time for the IP address from DHCP Server leased.

## 3.2 ETHERNET PORT

Ethernet Port section is used to access the port configuration and rate limit control. It also allows User to view port status and port trunk information.

Following items are included in this group:

3.2.1 Port Status

3.2.2 Port Setting

3.2.3 VLAN Setting

3.2.4 Traffic Control

### 3.2.1 Port STATUS

Port Status section allows users to see the current status from the Ethernet such as port state and speed/duplex

Port Status		
Port	Link	Speed/Duplex
1	Down	--
2	Down	--
3	Down	--
4	Up	1000 Full
5	Down	--

[Reload](#)

The description of the columns is as below:

TERMS	DESCRIPTION
Link	Display the Ethernet status, whether it is Link Up or Link Down.
Speed/Duplex	<b>Default: N/A</b> Show the Speed/Duplex for each port, such as 10 full,10 half,100 full,100 half mode for <b>Giga Ethernet Port 1~2 (ge1~ge2)</b>

Click on **Reload** to update the information.

### 3.2.2 Port SETTING

Use this page to configure the port setting such as the state and the speed / duplex for the Ethernet port.

**Port Settings**

Port	State	Speed/Duplex
1	Enable	AutoNegotiation
2	Enable	AutoNegotiation
3	Enable	AutoNegotiation
4	Enable	AutoNegotiation
5	Enable	AutoNegotiation

Submit Cancel

The description of the Ethernet Setting page is as below:

TERMS	DESCRIPTION
<b>Ethernet 1</b>	<p><b>Default: Enable</b></p> <p><b>Default: Auto / Auto-Negotiation</b></p> <p>Configure the Speed/Duplex of the port Ethernet 1. Users can set the bandwidth of each port as Auto-negotiation, 100 full, 100 half, 10 full, 10 half mode.</p>
<b>Ethernet 2</b>	<p><b>Default: Enable</b></p> <p><b>Default: Auto / Auto-Negotiation</b></p> <p>Configure the Speed/Duplex of the port Ethernet 2. Users can set the bandwidth of each port as Auto-negotiation, 100 full, 100 half, 10 full, 10 half mode.</p>
<b>Ethernet 3</b>	<p><b>Default: Enable</b></p> <p><b>Default: Auto / Auto-Negotiation</b></p> <p>Configure the Speed/Duplex of the port Ethernet 3. Users can set the bandwidth of each port as Auto-negotiation, 100 full, 100 half, 10 full, 10 half mode.</p>
<b>Ethernet 4</b>	<p><b>Default: Enable</b></p> <p><b>Default: Auto / Auto-Negotiation</b></p> <p>Configure the Speed/Duplex of the port Ethernet 4. Users can set the bandwidth of each port as Auto-negotiation, 100 full, 100 half, 10 full, 10 half mode.</p>
<b>Ethernet 5</b>	<p><b>Default: Enable</b></p> <p><b>Default: Auto / Auto-Negotiation</b></p> <p>Configure the Speed/Duplex of the port Ethernet 5. Users can set the bandwidth of each port as Auto-negotiation, 100 full, 100 half, 10 full, 10 half mode.</p>

Click **Submit** to apply the configuration that just made.

### 3.2.3 VLAN SETTINGS

The router's LAN port (Port 1-8) supports VLAN feature.

A VLAN is a group of devices that can be located anywhere on a network, but which communicate as if they are on the same physical segment. With VLANs, User can segment User network without being restricted by physical

connections—a limitation of traditional network design. To configure 802.1Q VLAN and port-based VLANs on the WoMaster switch, use the VLAN Settings page to configure the ports. User can assign Management VLAN, create the static VLAN, and assigns the Egress rule for the member ports of the VLAN.

The description of the columns is as below:

**VLAN Settings**

Management VLAN ID

**Add Static VLAN**

VLAN ID

**Static VLAN Settings**

VLAN ID	1	2	3	4	5	Select	Edit
1	U	U	U	U	U	<input type="checkbox"/>	<input type="button" value="Edit"/>
4094	--	--	--	--	--	<input type="checkbox"/>	<input type="button" value="Edit"/>
4093	--	--	--	--	--	<input type="checkbox"/>	<input type="button" value="Edit"/>

**PVID Settings**

Port	1	2	3	4	5
PVID	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>

The description of the Ethernet Setting page is as below:

TERMS	DESCRIPTION
<b>Management VLAN ID</b>	<b>Default : 1.</b> The switch supports management VLAN. The management VLAN ID is the VLAN ID of the CPU interface so that only member ports of the management VLAN can ping and access the switch.
<b>Add Static VLAN</b>	By select the VLAN and click the Edit button, user can assign a VLAN ID or VLAN Name and User can specify the egress (outgoing) port rule to be <b>Untagged or Tagged</b>
<b>Static VLAN Setting</b>	At this section user can edit the VLAN that has been added, include the name and egress rule.
<b>PVID Setting.</b>	The abbreviation of the <b>Port VLAN ID</b> . PVID allows the switches to identify which port belongs to which VLAN. To keep things simple, it is recommended that PVID is equivalent to VLAN IDs. The values of PVIDs are from 0 to 4095. But, 0 and 4095 are reserved. User can't input these 2 PVIDs. 1 is the default value. 2 to 4094 are valid and available in this column.

The steps to create a new VLAN: Type in Add Static VLAN section, and click **Submit** to create a new VLAN. Then User can see the new VLAN in the Static VLAN Setting table. After created the VLAN, the status of the VLAN will remain in Unused until User adds ports to the VLAN.

**NOTE:**

Before User changed the management VLAN ID by Web and Telnet, remember that the port attached by the administrator should be the member port of the management VLAN; otherwise the administrator can't access the switch via the network.

### 3.2.4 TRAFFIC CONTROL

Traffic control is a form of flow control used to enforce a strict bandwidth limit at a port. User can configure separate Incoming Outgoing rate limits and burst

**WWAN/WAN Traffic Control**

**Enable Traffic Control**

**Incoming Rate Limit**  kbps

**Incoming Burst**  kB

**Outgoing Rate Limit**  kbps

**Outgoing Burst**  kB

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enable Traffic Control</b>	Check the box to activate the function
<b>Incoming Rate Limit</b>	<b>Default: 1024000 kbit/s</b> Set the maximum incoming rate.
<b>Incoming Burst</b>	<b>Default: 20 kBytes</b> Set the maximum incoming burst.
<b>Outgoing Rate Limit</b>	<b>Default: 1024000 kbit/s</b> Set the maximum outgoing rate.
<b>Outgoing Burst</b>	<b>Default: 20 kBytes</b> Set the maximum outgoing burst.

Click on **Submit** to apply the configuration.

### 3.3 REDUNDANCY

Redundancy role of the network is to help protect critical links against failure, protects against network loops, and keeps network downtime at a minimum. Sustainable, uninterrupted data communication network is critical for industrial applications. Network Redundancy allows user to set up redundant loops in the network to provide a backup data transmission route in the event that a connection is inadvertently disconnected or damaged. This switch is supported with VRRP (Virtual Routing Redundancy Protocol). A VRRP (Virtual Router Redundancy Protocol) is a computer networking protocol aimed to eliminate the single point of failure by automatically assigning available IP routers to participating hosts. Using a virtual router ID (VRID) address and virtual router IP (VRIP) address to represent itself, a virtual router consists of two or more physical routers, including one master router and one or more backup routers. All routers in the virtual router group share the same VRID and VRIP. The master router provides primary routing and the backup routers monitor the status of the master router and become active if the master router fails. This is a particularly important feature for industrial applications, since it could take several

minutes to locate the disconnected or severed connection.

### 3.3.1 VRRP

#### VRRP Setting

The field allows user to create the Virtual Router Interface. All the routers/switches within the same VRRP domain should be located within the same IP network and equips with the same Virtual ID and Virtual IP address.

**VRRP**

**Enable VRRP**

**Virtual Router ID**

**Virtual IP**

**Priority**

**Adv. Interval**

**Preempt Mode**  Enable  Disable

**VRRP**

**Enable VRRP**

**Virtual Router ID**

**Virtual IP**

**Priority**

**Adv. Interval**

**Preempt Mode**  Enable  Disable

Click **Submit** once finish the configuration. Then a new entry is created in the Virtual Router Interface Status section below. After the VRRP interface is created, user can see the new entry and adjust the settings to decide the policy of the VRRP domain.

TERMS	DESCRIPTION
<b>Enable VRRP</b>	Check the box to enable the function.
<b>Virtual Router ID</b>	This is a virtual ID range from 1~255. The switches within the same VRRP domain should have the same Virtual ID.
<b>Virtual IP</b>	This is the virtual IP of the VRRP domain. This is the Gateway IP of the clients.
<b>Priority</b>	The priority of the entry of this switch. In VRRP domain, the VRRP router/ switches must have the same Virtual ID and Virtual IP settings and choose

	who should be the VRRP Master router/switch. The router/switch equips with the highest priority will be selected as the VRRP master. The priority setting field can be manually changed, the range is from 1~254, 255 for virtual IP owner and 100 for backup by default.
<b>Adv. Interval</b>	This field indicates how often the VRRP router/switches exchange the VRRP settings.
<b>Preempt</b>	<p>While the VRRP Master link is failure, the VRRP Backup will take over its job immediately. However, while the VRRP master link is recovered, who should be the Master? The Preempt decide whether the VRRP master should be recovered or not.</p> <p>While the Preempt is <b>Enable</b> and the interface is VRRP Master, the interface will be recovered.</p> <p>While the Preempt is <b>Disable</b> and the interface is VRRP Master, there is no change while the link is recovered. The VRRP backup acts as the Master before restarting the switches.</p>

Click the **Submit Selected** button to apply the configuration. Click the **Remove Selected** button to remove selected setting. Click the **Reload** button to reload table.

### VRRP Status

The VRRP represent the Virtual Router Redundancy Protocol. To further ensure the high reliability of an environment, the router/Layer 3 switch supports the VRRP protocol allowing the hosts to continuously direct traffic to the default gateway without the default gateway configuration change.

**Virtual Router Interface Status**

Select	Virtual ID	Virtual IP	Priority	Adv. Interval	Preempt	VRRP Status	VRRP Mac	Edit
<input type="checkbox"/>	1	192.168.10.6	100	1	1	Disable	00:00:5E:00:01:01	<a href="#">Edit</a>

[Delete Selected](#)   [Delete All](#)   [Refresh](#)

TERMS	DESCRIPTION
<b>Interface</b>	Show the interface for the VRRP domain.
<b>Virtual ID</b>	This is a virtual ID range from 1~255. The switches within the same VRRP domain should have the same Virtual ID.
<b>Virtual IP</b>	This is the virtual IP of the VRRP domain. This is the Gateway IP of the clients.
<b>Priority</b>	The priority of the entry of this router/switch. In VRRP domain, the VRRP router/switches must have the same Virtual ID and Virtual IP settings and choose who should be the VRRP Master router/switch. The router/switch equips with the highest priority will be selected as the VRRP master. The

	priority setting field can be manually changed, the range is from 1~254, 255 for virtual IP owner and 100 for backup by default.
<b>Adv. Interval</b>	This field indicates how often the VRRP switches exchange the VRRP settings.
<b>VRRP Status</b>	While the VRRP Master link is failure, the VRRP Backup will take over its job immediately
<b>VRRP MAC</b>	This field indicates the VRRP MAC in this configuration entry.


Click **Refresh** to refresh the list. Click **Select** to the specific list then user can do several actions such as **Edit** and **Delete Selected**. Click **Delete All** to delete all of the list.

### 3.4 SERIAL (Reserved)

**Note:** The feature is reserved for the WR315GR-2C with Serial port model only.

This router with serial port model equips with one serial port which are RS232/422/485 ports that able to connect to local serial devices (Refer to the Appendix). And these serial ports support TCP Server, TCP Client, and UDP Listening. From the web management interface, it has two configuration pages for Serial 1.

**Below is the pin assignment**



Pin	RS232	RS485-4w/422	RS485-2w
1	DCD	TX-	Data-
2	TXD	RX+	-
3	RXD	TX+	Data+
4	DSR	-	-
5	GND	GND	-
6	DTR	RX-	-
7	CTS	-	-
8	RTS	-	-
9	RI	-	-

RS-232 is the most common serial interface and used to ship as a standard component on most Windows-compatible desktop computers. Now it is more common to use RS-232 over USB using a converter. RS-232 only allows for one transmitter and one receiver on each line. RS-232 also uses a Full-Duplex transmission method.

RS422 is an improved version of RS232, it uses twisted pair cable to reduce the noise, and it uses signaling balancing to transmit data, so what is signal balanced – It uses a voltage-difference between the two lines as an indication of the signal value, with this method the data is able to transmit for longer distance with faster data rates, with RS422 the data can transmit up to 10 Mbps at 50 feet or 100 Kbps at 4000 feet. RS422 is capable of multi-drop capability, it limits up to 10 slaves in the data line.

RS-485 is a superset of RS-422 and expands on the capabilities. RS-485 was made to address the multi-drop limitation of RS-422, allowing up to 32 devices to communicate through the same data line. Both RS-485 and RS-422 have multi-drop capability, but RS-485 allows up to 32 devices and RS-422 has a limit of 10.

## Serial 1

This configuration page is an interface to configure the serial setting.

Serial1

### Serial Port 1 Settings

**Basic Settings**

**Interface**

**Baudrate**

**Parity**

**Databit**

**Stopbit**

**Flow Control**

**Terminal Resistor**

**Service Mode**

**Force Tx Interval**  (ms) data will be queueing in Tx buffer until tx interval timeout

**Force Tx Length**  (bytes) (0~1024) Tx data before force timeout expires

Serial to Ethernet Delimiter (0~255 or HEX)

**Delimiter1**  **Delimiter2**  **Delimiter3**  **Delimiter4**

**Flush time**  (ms)



Ethernet to Serial Delimiter (0~255) or HEX

**Delimiter1**  **Delimiter2**  **Delimiter3**  **Delimiter4**

**Flush time**  (ms)

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Interface</b>	<b>Default : RS422</b> Choose and change the interface type from the drop down list. The serial port supports the RS232, RS422, RS485-2w, and RS485-4w.
<b>Baudrate</b>	<b>Default: 38400</b> Serial baud rate, a speed measurement of communication. It indicates the number of bit transfers per second.

	<p> <b>Baudrate</b> 38400  <b>Parity</b>  <b>Databit</b>  <b>Stopbit</b>  <b>Flow Control</b>  <b>Terminal Resistor</b>  <b>Force Tx Interval</b>  <b>Force Tx Length</b>  <b>Service Mode</b> </p> 
<b>Parity</b>	<p><b>Default: NONE</b></p> <p>Set parity bit of serial data.</p>  <p>For even and odd parity, the serial port will set the parity bit (the last bit after the data bits) to a value to ensure that the transmission has an even or odd number of logic high bits. Mark and space parity does not actually check the data bits, but simply sets the parity bit high for marked parity or low for spaced parity.</p>
<b>Databit</b>	<p><b>Default: 8 bits</b></p> <p>Indicates the number of bits in a transmitted data package.</p>
<b>Stopbit</b>	<p><b>Default: One Stopbit</b></p> <p>The stop bit follows the data and parity bits in serial communication. It indicates the end of transmission.</p>
<b>Flow Control</b>	<p><b>Default: NONE</b></p> <p>Flow control manages data flow between devices in a network to ensure it is processed efficiently. Too much data arriving before a device is prepared to manage it causes lost or retransmitted data.</p>
<b>Terminal Resistor</b>	<p><b>Default: Disable</b></p> <p>Enable to prevent serial signal reflection.</p>
<b>Service Mode</b>	<p>Choose TCP Server, TCP Client, and UDP listening.</p>
<b>Force TX Interval</b>	<p><b>Default: 0 (ms)</b></p> <p>Force TX interval time is to specify the timeout when no data has been transmitted and queue data before the time interval is expired.</p>
<b>Force TX Length</b>	<p><b>Default: 1024 (bytes)</b></p> <p>To specify the length of the data before Force timeout expires.</p>
<b>Serial to Ethernet</b>	<p><b>Delimiter:</b> User can define max. 4 delimiters (0~255, Hex) for each way.</p>

	<p>The data will be held until Flush Time is expired. 0 means disable. The factory default is 0.</p> <p><b>Flush Time:</b> The received data will be queued in the buffer until all the delimiters are matched. When the Flush Time is expired the data will be sent.</p>
<b>Ethernet to Serial</b>	<p><b>Delimiter:</b> User can define max. 4 delimiters (0~255, Hex) for each way. The data will be held until Flush Time is expired. 0 means disable. The factory default is 0.</p> <p><b>Flush Time:</b> The received data will be queued in the buffer until all the delimiters are matched. When the Flush Time is expired the data will be sent.</p>

The other section from this Serial page is TCP Server Mode Config. This page allows user to configure the basic settings of TCP Server Mode.

**TCP Server Mode Config:**

**TCP Port:**

**Max Connection:**

**Idle Timeout(sec):**

**Alive Check(sec):**

The description of the columns is as below:

TERMS	DESCRIPTION
<b>TCP Port</b>	<p><b>Default: Serial 1 – 4000, Serial 2 - 4002</b></p> <p>Assign the available TCP port number. The port number of TCP Server and TCP Client should be the same.</p>
<b>Max Connection</b>	Configures the maximum connection number from 1 to 5.
<b>Idle Timeout (sec)</b>	When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disabled this setting (default). If Multilink is configured, only the first host connection is effective for this setting.
<b>Alive Check (sec)</b>	The device will send a TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. If user sets it as zero, it means disable this setting.

## 3.5 CELLULAR

This Cellular page provides the Cellular Status; configure Cellular Setting, and configure SIM Setting. WoMaster Industrial Router is supported with redundant SIM and Dual SIM Card; user can choose SIM1 or SIM2 for the main SIM Card.

### 3.5.1 CELLULAR STATUS

The figure below shows Cellular Status.

#### Cellular Status


**Cellular/ETH-WAN Redundancy**

**Cellular1**

<b>Modem Status</b>	<input type="text" value="Normal"/>
<b>Interface Status</b>	<input type="text" value="Enable"/>
<b>Version</b>	<input type="text" value="MR3.01b03.03.00"/>
<b>Network Registration</b>	<input type="text" value="Registered (home network)"/>
<b>Network Search Mode</b>	<input type="text" value="Auto"/>
<b>Current SIM index</b>	<input type="text" value="1"/>
<b>Provider</b>	<input type="text" value="46689"/>
<b>APN</b>	<input type="text" value="internet"/>
<b>Service Type</b>	<input type="text" value="E-UTRAN"/>
<b>Band</b>	<input type="text" value="7"/>
<b>IMEI</b>	<input type="text" value="861660050013654"/>
<b>IMSI</b>	<input type="text" value="466891004389151"/>
<b>Cell ID</b>	<input type="text" value="003865934"/>
<b>MCC MNC</b>	<input type="text" value="466 89"/>
<b>Signal Strength</b>	<input type="text" value="-87 dBm(Medium)"/>
<b>RSRP</b>	<input type="text" value="-101 dBm"/>
<b>RSRQ</b>	<input type="text" value="-15 dB"/>
<b>SIM Status</b>	<input type="text" value="SIM OK"/>
<b>Connection Status</b>	<input type="text" value="Connected"/>
<b>IP Address</b>	<input type="text" value="100.87.10.202"/>

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Cellular/ETH.WAN Redundancy</b>	<b>Default: Disabled</b> User can choose the redundancy mode:

	<p><b>Cellular/ETH-WAN Redundancy</b> </p> <p><b>ETH-WAN First, Cellular-WAN Backup:</b> by choosing this mode, the redundancy mode would be like prioritize the ETH-WAN connection; if the ETH-WAN connection has a problem then the Cellular-WAN would be the backup connection.</p> <p><b>Cellular-WAN First, ETH-WAN Backup:</b> by choosing this mode, the redundancy mode would be like prioritize the Cellular-WAN connection; if the Cellular-WAN connection has a problem then the ETH-WAN would be the backup connection.</p>
<b>Modem Status</b>	Display the modem status
<b>Interface Status</b>	Display the Cellular interface status Enabled or Disabled
<b>Version</b>	Display the firmware version of the cellular module.
<b>Network Registration</b>	Display the status of the network registration
<b>Network Search Mode</b>	Display the network search mode (Auto, 2G Only, 3G Only and LTE Only)
<b>Current SIM Index</b>	Display the current in used SIM card (1 or 2)
<b>Provider</b>	Display the ISP (MCC+MNC) that user used.
<b>APN</b>	Every ISP has a specific APN (Access Point Name) assigned to its cellular network. The system can read this name from the SIM card.
<b>Service Type</b>	The connected ISP will update the service type here. The possible types are GSM – 2G, UMTS – 3G, GSM W/EGPRS, UTRAN W/HSDPA (download), UTRAN W/HSUPA(upload), UTRAN W/HSDPA and HSUPA(download & upload), E-UTRAN - LTE , No Service(default value)
<b>Band</b>	Display the connected band
<b>IMEI</b>	Display the International Mobile Equipment Identity (IMEI)
<b>IMSI</b>	Display the International Mobile Subscriber Identity (IMSI)
<b>Cell ID</b>	Display the Cell Identity (CID)
<b>Signal Strength</b>	<p>The signal strength to the remote connected base station. If the signal strength shows low, please change the device location or mounting the antenna in better location.</p> <p>Below are the signal strength definitions in our system:</p> <p>Low: -113 dBm or less~-95 dBm</p> <p>Medium: -93 dBm ~ -85 dBm</p> <p>Good: -83dBm ~-75 dBm</p> <p>Excellent:-73 dBm ~-51 dBm</p> <p>Not known or not detectable: No base station detected</p>
<b>RSRP</b>	Display the RSRP(Reference Signal Received Power) value. The higher value indicates better signal power.
<b>RSRQ</b>	Display the RSRQ (Reference Signal Received Quality) value. The higher value indicates better signal quality.

<b>SIM Status</b>	<p>Show the installed SIM Status.</p> <p><b>SIM OK:</b> The SIM card is okay to use.</p> <p><b>SIM not inserted:</b> The SIM card is not inserted.</p> <p><b>SIM PIN Locked:</b> The SIM card is locked due to PIN error. It may be caused by error typing PIN password many times.</p> <p><b>SIM PUK Locked:</b> The SIM Card PUK is locked due to PIN error after user three times input the wrong password. Contact the ISP to resolve the issue.</p>
<b>Connection Status</b>	<p><b>Connection Status:</b></p> <p><b>Connected:</b> The cellular interface is connected.</p> <p><b>Not Connected:</b> The cellular interface is not connected.</p>
<b>IP Address</b>	<p>The IP Address assigned by the ISP. While the cellular is connected, the IP address will display here.</p>

### 3.5.2 CELLULAR SETTING

This section displays the Cellular Setting configuration page and also in this configuration page user may activate the redundant SIM function. In this section, user may Enable/Disable the Cellular Interface, SIM Selection, Cellular Redundant, Network Type; SIM 1/2 settings include the Operation code (MCC+MNC), APN, User Name, Password and the Authentication mode. The system will check the status of the cellular module every few seconds, if it can't be configured, please wait a few second or refresh the web interface. After you changed the setting, the router will reconnect to the base station and you will need to wait couple seconds for the new connection.

The figure below is the interface of the router:

The description of the columns is as below:

TERMS	DESCRIPTION
<p><b>Cellular/ETH.WAN Redundancy</b></p>	<p><b>Default: Disabled</b></p> <p>User can choose the redundancy mode:</p> <div style="border: 1px dashed gray; padding: 5px; margin: 10px 0;"> <p><b>Cellular/ETH-WAN Redundancy</b> <span style="border: 1px solid gray; padding: 2px;">ETH-WAN First, Cellular-WAN Backup</span></p> <p style="margin-left: 20px;">ETH-WAN First, Cellular-WAN Backup</p> <p style="margin-left: 20px;">Cellular-WAN First, ETH-WAN Backup</p> </div> <p><b>ETH-WAN First, Cellular-WAN Backup:</b> by choosing this mode, the redundancy mode would be like prioritize the ETH-WAN connection; if the ETH-WAN connection has a problem then the Cellular-WAN would be the backup connection.</p> <p><b>Cellular-WAN First, ETH-WAN Backup:</b> by choosing this mode, the redundancy mode would be like prioritize the Cellular-WAN connection; if the Cellular-WAN connection has a problem then the ETH-WAN would be the backup connection.</p>

<b>Cellular Interface</b>	To enable or disable the cellular interface. Click check to disable the function.
<b>SIM Selection</b>	<p><b>Default: SIM1</b></p> <p>User can select the SIM card 1 or 2 that want to be activated or used.</p> <p>Not every model supports dual SIM, if the hardware doesn't support dual SIM, the SIM2 setting is not available.</p>
<b>Cellular Redundant</b>	<p><b>Default: Disable</b></p> <p>By enable this function, the SIM redundant function will be activated. The main function of this feature is to have the backup SIM if the main SIM card is unable to use or have a problem connection.</p> <div style="border: 1px dashed black; padding: 5px; margin: 10px 0;"> <p><b>Cellular Redundant</b> <input checked="" type="radio"/> Enable <input type="radio"/> Disable</p> <p><b>Redundant Parameters</b></p> <p><b>Period</b> <input type="text" value="30 sec"/> <input type="button" value="v"/></p> <p><b>Number of Retries</b> <input type="text" value="3"/> (1-10)</p> </div> <p><b>Redundant Parameters</b> configuration appears after the user enables the function. If the SIM card cannot be read after the redundant parameters are expired then it will directly change to read the other SIM card.</p> <p><b>Period:</b> Set the period time to read the SIM card. The default value is 30 Seconds.</p> <p><b>Number of Entries:</b> Set the number of entries to give the remaining trial to read the SIM card. The default value is 3.</p>
<b>Network Type</b>	<p>Set the Network Type, the option would be:</p> <p><b>Auto: Search the network automatically</b></p> <p><b>2G Only: only receive the 2G signal.</b></p> <p><b>3G Only: only receive the 3G signal.</b></p> <p><b>LTE Only: only receive LTE/4G signal.</b></p> <p><b>NR5G: only receive the 5G NR signal, or known as 5G NR SA mode.</b></p> <p><b>LTE+NR5G: available to receive the 5G NR signal, or known as 5G NR NSA mode.</b></p> <p>The network type in different models is different. The GUI only shows the available type.</p>
<b>SIM1/2 APN</b>	Set the APN of the carrier provider.
<b>SIM1/2 Operation Code(MCC+MNC)</b>	<p>Set the <b>MCC Mobile Country Code) + MNC (Mobile Network Code)</b> of the carrier provider.</p> <p>You can get the number while you apply the service from your carrier provider. For example, the 46692 represents MCC=466 + MNC=92. The 466 represent for Taiwan, 92 represent for Chunghwa Telecom LDM, the network provider in Taiwan.</p> <p><b>Note:</b> We have APN/MCC+MNC code of the known providers written into our system, but, it may not cover all countries/operators. If you can't connect to internet, please double check the APN and MCC+MNC code and enter the correct number manually.</p>
<b>SIM1/2 User Name</b>	Set the User Name
<b>SIM1/2 Password</b>	Set the password.
<b>SIM1/2 Authentication</b>	<p>Choose CHAP or PAP mode for the authentication mode.</p> <p><b>CHAP:</b> Challenge Handshake Authentication Protocol, With CHAP, the authenticator (i.e. the server) sends a randomly generated "challenge" string to the client, along with its</p>

	<p>hostname.</p>
--	------------------

**PAP:** Password Authentication Protocol, PAP works basically the same way as the normal login procedure. The authenticates itself by sending a user name and a password to the server

Click **Submit** to apply the configuration.

### 3.5.3 SIM SETTING

This section displays the SIM configuration such as SIM Status and SIM pin configuration. And in this section, user can enable or disable the SIM protection function. Apply the PIN number to the SIM cards; and make sure user enters the correct PIN number when activating the connection, after that the connection will start working. And also user can change the new PIN settings.

The figure below belongs to the single SIM model:

#### SIM Setting

SIM Status	SIM OK
Number of Retries Remain:	2
SIM1 PIN:	<input type="text"/>
Confirm SIM1 PIN:	<input type="text"/>
Remember PIN:	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
PIN Protection: <b>Disable</b>	Disable PIN ▼

The figure below belongs to two SIM models. It indicates the Current SIM Index section. To configure SIM 2 security, you need to select the SIM 2 in SIM selection of the cellular setting page first.

#### SIM Setting

Current SIM Index	2
SIM Status	SIM not inserted
SIM2 PIN	<input type="text"/>
Confirm SIM2 PIN	<input type="text"/>
Remember PIN	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
PIN Protection <b>Enable</b>	Disable PIN ▼

TERMS	DESCRIPTION
<b>Current SIM Index</b>	Display the current in used SIM Card slot (1 / 2)
<b>SIM Status</b>	Show the installed SIM Status.  <b>SIM OK:</b> The SIM card is okay to use.  <b>SIM not inserted:</b> The SIM card is not inserted.  <b>SIM PIN Locked:</b> The SIM card is locked due to PIN error. It may be caused by error typing PIN password many times.

	<div style="border: 2px solid red; padding: 5px;"> <p><b>WARNING:</b> SIM PUK Locked status will appear when the SIM Card PUK is locked due to PIN error after user three times input the wrong password. Contact the ISP to resolve the issue.</p> </div>
<b>Number of Retries Remain</b>	Display the remaining chance to enter the PIN numbers.
<b>SIM1/2 PIN</b>	Enter new SIM1/2 PIN numbers
<b>Confirm SIM1/2 PIN</b>	Confirm the new SIM1/2 PIN numbers
<b>Remember PIN</b>	Click enable to save the PIN numbers
<b>PIN Protection</b>	<p>Activate the PIN protection feature. Choose the mode from the drop list.</p> <p><b>Disable PIN:</b> Disable the PIN Protection feature</p> <p><b>Enable PIN:</b> Activate the PIN Protection feature</p> <p><b>Change PIN:</b> Change the PIN number, make sure user type the new PIN Number first at the SIM1 PIN textbox.</p>

Click **Submit** to apply the configuration.

### 3.5.4 Cellular Diag

The Cellular Diag is used to get further information for the device of cellular records.

**Cellular Diagnosis**

[Generate Diagnosis File](#)
**Generate**

[Download Diagnosis File](#)
**Download**

TERMS	DESCRIPTION
<b>Generate Diagnosis File</b>	Klick the button <b>“Generate”</b> . The popup screen will ask <b>“Are you sure to generate it now?”</b> Click <b>“Yes/Sure”</b> and wait for 10s to generate the log file.
<b>Download Diagnosis File</b>	You can view the diagnostic information in the web page. You can also klick the button <b>“Download”</b> to download the diagnosis log file. You can send the file to our engineer for further diagnosis.

### 3.5.5 CELLULAR/WAN REDUNDANCY

The feature allows user setup the WAN to Cellular redundancy while Ethernet-WAN port link down or unexpected failure, the cellular is activated automatically. Before enabled the feature, you should enabled the Ethernet Setting in Router mode, which means the two Ethernet ports are separated to different network interface, the port 1 acts as WAN port and port 2 acts as LAN port.

Home > Ethernet Port > Eth Settings

Eth Status
Eth Settings

**Ethernet Settings**

Network Mode
Router

The Cellular/Eth-WAN Redundancy setup page:

#### Cellular/ETH-WAN Redundancy

**Cellular/ETH-WAN Redundancy** ETH-WAN First,Cellular-WAN Backup

Enable Eth-WAN Ping Tracking

Ping IP Address 8.8.8.8

Ping Interval 3 seconds

Startup Delay 120 seconds

Ping Fail Counter 4

Submit
Cancel

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Cellular/Eth-WAN Mode</b>	Choose which is the main WAN interface and which is backup? <b>ETH-WAN First, Cellular-WAN Backup (Default) or Cellular-WAN First, Eth-WAN Backup:</b>
<b>Enable Eth-WAN Ping Tracking</b>	You can enable the Ping tracking to check the active status of the WAN interface. After enabled and configured following settings, the router will continuously check the status of the target IP address, once the router can't pin the target IP, the backup interface will be activated immediately.
<b>Ping Interval</b>	Ping interval time, default: 3 second
<b>Startup Delay</b>	The router starts Ping tracking after the Startup Delay time. Default: 120 Note: Considering the WAN interface may not get IP immediately after system startup, please remain startup delay time longer.
<b>Ping Fail Counter</b>	The counter indicates how many times ping fail means WAN interface failure. Default: 4

### 3.5.6 DDNS SETTING

The DDNS (Dynamic Domain Name Service) is a method of keeping a domain name mapping to a dynamic public IP address. A dynamic public IP address is assigned for every connection request. After the user sets up the DDNS service, the DDNS service provider will automatically update the connection information if the public IP address has been changed. In this section, the user may configure the DDNS Setting.

**DDNS Settings**

Enable Dynamic DNS

Service Provider

Domain Name

Login Name

Password

Confirm Password

TERMS	DESCRIPTION
<b>Enable Dynamic DNS</b>	Check the box to enable the function
<b>Service Provider</b>	Select the Domain service provider from the list.

	<div style="border: 1px solid black; padding: 5px;"> <p><b>Service Provider</b></p> <div style="border: 1px solid black; padding: 2px;"> <p>www.dyn.com(dynamic) ▼</p> <p>www.dyn.com(dynamic)</p> <p>www.dyn.com(custom)</p> <p>www.dyn.com(static)</p> <p>www.no-ip.com</p> <p>dynamic.zoneedit.com</p> </div> </div>
<b>Domain Name</b>	Enter the domain name
<b>Login Name</b>	Enter Login Name that used when applying the domain name
<b>Password</b>	Enter Password that used when applying the domain name
<b>Confirm Password</b>	Enter the Password once again to confirm.

After finishing configure any of the above setting, click on **“Submit”** to apply the configuration. Click **“Save -> Save to Flash”** to permanently save the configuration.

### 3.5.7 SMS REMOTE Control

**SMS Remote Control**

SMS Remote Control  Enable

User can send the SMS message to reboot the router from the cellphone. The SMS message format is **“User Name, Password, reboot”**. For example: **“admin, Admin@123, reboot”**.

Note: The router support SMS message to reboot router currently, if you have other need, please contact our Sales/Service div., we can discuss this by project need.

### 3.5.8 SMS Alert

SMS alerts, also known as SMS notifications or text alerts, are messages that are automatically sent to subscribers who have indicated that they want to receive text messages.

**SMS Alert**

**SMS Alert**  Enable

**Periodical SMS**  Enable

**Periodical SMS Interval**  minutes

**To phone number 1**

**To phone number 2**

**To phone number 3**

**To phone number 4**

The description of the columns is as below:

TERMS	DESCRIPTION
<b>SMS Alert</b>	Select the SMS Alert to Enable
<b>Periodical SMS</b>	Select the Periodical SMS Alert to Enable
<b>Periodical SMS Interval</b>	Set the Periodical SMS Interval time
<b>To phone number 1</b>	Set the phone number
<b>To phone number 2</b>	Set the phone number
<b>To phone number 3</b>	Set the phone number
<b>To phone number 4</b>	Set the phone number

### 3.6 GPS

This GPS section has the function to show the current position of the device. The purpose of this feature is to display the location of each device if there is device installation in large number. It could help the technician to track the device location. WoMaster GPS feature is supported with the Global Navigation Satellite Systems use satellite technology to provide insight on the geographic location of connected devices. GNSS is an inclusive term for the category of global systems including GPS, GLONASS, BeiDou, and Galileo. Modern positioning and timing modules have evolved to take advantage of multiple GNSS constellations at once. Combining multiple satellite systems improves availability of signals, gives operators more access, and increases accuracy. Recent driving tests combining GPS and GLONASS showed a noticeable improvement in both precision and performance when compared with single system results. Whether user is navigating a position in a crowded city, a vast desert, or a dense forest, utilizing multiple GNSS systems can help the device stays connected and centered.

#### 3.6.1 GPS STATUS

The first configuration page is GPS Status, where user can see all of the GPS information such as the GPS Status, Date, UTC, Latitude, Longitude, Altitude (m), Speed over ground(Km/h) and the Number of satellites.


TERMS	DESCRIPTION
Status	Display the GPS interface status OK or Disabled
Date	Display the current date.
UTC	Display the Coordinated Universal Time (UTC)
Latitude	Display the latitude of the coordinate
Longitude	Display the longitude of the coordinate
Altitude(m)	Display the altitude of the coordinate show the height or distance of an object from sea level.

The description of the columns is as below:

TERMS	DESCRIPTION
Status	Display the GPS interface status OK or Disabled
Date	Display the current date.
UTC	Display the Coordinated Universal Time (UTC)
Latitude	Display the latitude of the coordinate
Longitude	Display the longitude of the coordinate
Altitude(m)	Display the altitude of the coordinate show the height or distance of an object from sea level.

<b>Speed over ground(Km/h)</b>	Display the speed over ground.
<b>Number of satellites</b>	Display the number of satellites that help to fix the position (Minimum 4 satellites).

At the status section, a MAP button appears. Click this button to show the specific location of your device through the Google Maps. After user clicks the button, the figure below will be appeared.



### 3.6.2 GPS SETTING

In this GPS Setting section, user can enable/disable the GPS Interface or Type specific GPS location by User Input.

#### GPS Settings

**GPS Profile**

**GPS Mode**

Disable

GPS

User Input

Latitude

Longitude

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Disable</b>	Display the GPS interface status OK or Disabled
<b>GPS</b>	Enable the GPS interface. Note that the GPS antenna must be installed.
<b>User Input</b>	Type the specific Latitude and Longitude address for your router.

## 3.7 SECURITY

WoMaster Router provides several security features for User to secure access to its management functions and it can be remotely managed (monitored and configured).

The following topics are included in this section:

3.7.1 Access Control

3.7.2 Outbound Firewall

3.7.3 NAT Setting

3.7.4 OpenVPN

3.7.5 IPSec Setting

3.7.6 L2TP Settings

### 3.7.1 ACCESS CONTROL

WoMaster router provides access control mode in several ways, such as Remote Management, WAN Service Access Control and Custom Exception. By configuring this configuration, user can enhance the security access to the device.

#### **Remote Management**

Remote Management function, open the Remote Management, that would allow the user via the local access (WAN Port) Remote Management the router.

### Remote Management

Service	Enable
Telnet	<input checked="" type="checkbox"/> Enable
SNMP	<input checked="" type="checkbox"/> Enable
SSH	<input type="checkbox"/> Enable
HTTPS Only	<input type="checkbox"/> Enable


The description of the columns is as below:


TERMS	DESCRIPTION
<b>Telnet</b>	Allows the user to remotely login and manage the device by Telnet. When user doesn't enable it, the connection through telnet will not allow.
<b>SNMP</b>	Allows the user to remotely login and manage the device by SNMP. When user doesn't enable it, the connection through SNMP will not allow.
<b>SSH</b>	Allows the user to remotely login and manage the device by SSH/ When user doesn't enable it, the connection through SSH will not allow.
<b>HTTPS Only</b>	Allows the user to remotely login and manage the device by HTTPS access for secure connection, and it would disable the HTTP access.

Once User finishes configuring the settings, click on **Submit** to apply configuration.

## HTTPS Only

HTTP Secure is the use of the HTTP protocol over an SSL/TLS protocol. It is used primarily to protect against eavesdropping of communication between a web browser and the web site to which it is connected. This is especially important when you wish to have a secure connection over a public network such as the internet. HTTPS connections are secured through the use of certificates issued by trusted certificate authorities. When a web browser makes a connection attempt to a secured web site, a digital certificate is sent to the browser so that it can verify the authenticity of the site using a built-in list of trusted certificate authorities.





### Your connection is not private

Attackers might be trying to steal your information from **192.168.10.1** (for example, passwords, messages, or credit cards). [Learn more](#)

NET::ERR\_CERT\_AUTHORITY\_INVALID

Automatically send some [system information and page content](#) to Google to help detect dangerous apps and sites. [Privacy policy](#)

HIDE ADVANCED Back to safety

This server could not prove that it is **192.168.10.1**; its security certificate is not trusted by your computer's operating system. This may be caused by a misconfiguration or an attacker intercepting your connection.

[Proceed to 192.168.10.1 \(unsafe\)](#)

If user uses the HTTPS Only, a warning page would appear when user access the device in order to provide a secure access. The picture above is the warning message about the digital certificate and user just need to accept this warning by click "**Proceed to 192.168.10.1 (unsafe)**".

## WAN Access

When user changes the device mode to **router mode (Port 1 – WAN interface)** the WAN Access feature can be activated. This feature is about the exception to access the device through the WAN interface for security concern. So that the access or the traffic that coming through the WAN interface can be limited as required. The user may choose the **Filter All** functions to block all access from the WAN interface or enable the exception options, then the router allows user to remotely access to the router from WAN interface.

Service	(W)WAN (Exception)
Web	<input type="checkbox"/> Enable
Telnet	<input type="checkbox"/> Enable
SSH	<input type="checkbox"/> Enable
SNMP	<input type="checkbox"/> Enable

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Filter All</b>	By select Filter All, it will block all external access from WAN interface to the device (such as SSH, SNMP, Web and Telnet) and unblock the exception options.
<b>Web</b>	Select this option to allow access to the router using Web (HTTP or HTTPS) from the WAN Interface
<b>Telnet</b>	Select this option to allow access to the router using Telnet from the WAN Interface
<b>SSH</b>	Select this option to allow access to the router using SSH from the WAN Interface
<b>SNMP</b>	Select this option to allow access to the router using SNMP from the WAN Interface

Once User finishes configuring the settings, click on **Submit** to apply configuration.

## Custom Exception

Another choice for the access control is also provided by WoMaster, it is called custom exception feature. Through this feature, it can help to allow the incoming access through the firewall to local devices. If the condition does not meet the requirement from the table, then the access would be denied.

Access Control ▾
Outbound Firewall ▾
NAT Setting ▾
OpenVPN ▾
IPSec Setting

### Custom Exception

**Incoming IP Address:**

**Src Port Range:**  -

**Dest Port Range:**  -

**Comment:**

Src IP Address ↕	Src Port Range ↕	Dest Port Range ↕	Comment ↕	Select	Edit
192.168.10.2	1-2	1-10		<input type="checkbox"/>	<input type="button" value="Edit"/>

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Src IP Address</b>	Set up the source IP Address that may access the device.
<b>Src Port Range</b>	Set up the source port range where the access came from.
<b>Dest Port Range</b>	Set up the destination port range where the access is going to.
<b>Comment</b>	Put any notes for the entry.
<b>Select</b>	Select the table, so user can press <b>Delete Selected</b> to delete,
<b>Edit</b>	Click edit to modify the parameters

Once User finishes configuring the settings, click on **Submit** to apply configuration and a new line will directly appear on the table.

### 3.7.2 OUTBOUND FIREWALL

WoMaster' router has different types firewall settings, user can enable the setting, configure the rules. The following section is Outbound Firewall Settings pages where user can configure the Outbound Firewall setting.

TERMS	DESCRIPTION
Source IP Filter	Source IP addresses Filtering from LAN to Internet through the router.
Destination IP Filter	Destination IP addresses Filtering from the LAN to Internet through the router.
Source Port Filtering	Source Ports Filtering from the LAN to Internet through the router.
Destination Port Filtering	Destination Ports Filtering from the LAN to Internet through the router

#### Src IP Filter

By entries parameter in this table, it can restrict certain types of data packets from the local network to the internet through the Router. The Source IP Filter will help to filter all of the packets that coming into the router. If the source IP is on the list, then the packets would be dropped. But if the source IP is not on the list, then the packets can be received. Select **Enable** to activate **Source IP Filtering**, type the **Local IP Address** and **Comment** to write notes for the entry. Click Submit to activate the settings. After applied, then user can see the new entry shown in the below table.

Access Control ▾
Outbound Firewall ▾
NAT Setting ▾
OpenVPN ▾
IPSec Setting

### Source IP Filter

Source IP Filter:  Enable

Local IP Address:

Comment:

Local IP Address	Comment	Select	Edit
192.168.10.4		<input type="checkbox"/>	<input type="button" value="Edit"/>

The description of the columns is as below:

TERMS	DESCRIPTION
Local IP Address	Display the Source IP address.
Comment	Put any notes for the entry.
Select	Select the table, so user can press <b>Delete Selected</b> to delete,
Edit	Click edit to modify the parameters

Click **Refresh** to refresh the table

## Dest IP Filter

By entries parameters in this table are used to restrict the computers in LAN from accessing certain websites in WAN according to IP address. The concept is the same as the source IP Filter. The packet would not send to the specific IP Address that showed on the list. Only the IP Address that shows on the list that cannot receive the packets. Select **Enable** to activate **Destination IP Filtering**, type the **Destination IP Address** and **Comment** to write a note for the entry and then click Submit to apply the settings. After applied, then user can see the new entry shown in the below table.

Access Control ▾ **Outbound Firewall** ▾ NAT Setting ▾ OpenVPN ▾ IPsec Setting

### Destination IP Filter

**Destination IP Filter:**  Enable

**Destination IP Address:**

**Comment:**

Destination IP Address	Comment	Select	Edit
192.168.10.3	<input type="text"/>	<input type="checkbox"/>	<input type="button" value="Edit"/>

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Destination IP Address</b>	Display the Destination IP address.
<b>Comment</b>	Put any notes for the entry.
<b>Select</b>	Select the table, so user can press <b>Delete Selected</b> to delete,
<b>Edit</b>	Click edit to modify the parameters

Click **Refresh** to refresh the table

## Src Port Filter

Entries in this table are used to restrict certain ports of data packets from user's local network to the Internet through the Router. Use of such filters can be helpful in securing or restricting local network. The device just cannot receive any packets from the source port that showed on the list, the other packet that sent from any source port that not on the list would be received.

Select **Enable Source Port filtering**, type the **Port Range** of below **Protocol** type, the protocol type can be **UDP, TCP or Both**. Type the **Comment** to write a note for the entry and then click **Submit** to activate the settings.

After applied, user can see the new entry shown in the below table.

Access Control ▾ | Outbound Firewall ▾ | NAT Setting ▾ | OpenVPN ▾ | IPsec Setting

### Source Port Filter

**Source Port Filter:**  Enable

**Port Range:**  -

**Protocol:**

**Comment:**

Source Port Range	Protocol	Comment	Select	Edit
1-10	TCP+UDP		<input type="checkbox"/>	<input type="button" value="Edit"/>

The description of the columns is as below:

TERMS	DESCRIPTION
Source Port Range	Display the Source Port Range (Range is from 1 to 65535)
Protocol	Display the protocol that has been chosen by the user.
Comment	Put any notes for the entry.
Select	Select the table, so user can press <b>Delete Selected</b> to delete,
Edit	Click edit to modify the parameters

Click **Refresh** to refresh the table

## Dest Port Filter

Entries in this table are used to restrict certain ports of data packets from user's local network to Internet through the router. Use of such filters can be helpful in securing or restricting local network. And the device cannot send any packets to the destination port that showed on the list.

Select **Enable Destination Port Filtering**, type the **Port Range** of below **Protocol** type, the protocol type can be **UDP, TCP or Both**. Type the **Comment** to write note for the entry and then press **Submit** to apply the settings.

After applied, then user can see the new entry shown in the below table.

Access Control ▾
Outbound Firewall ▾
NAT Setting ▾
OpenVPN ▾
IPSec Setting

### Destination Port Filter

**Destination Port Filter:**  Enable

**Port Range:**  -

**Protocol:** Both ▾

**Comment:**

Submit
Cancel

Dest Port Range ↕	Protocol ↕	Comment ↕	Select	Edit
1-10	TCP+UDP		<input type="checkbox"/>	<span style="border: 1px solid black; padding: 2px 5px;">Edit</span>

Delete Selected
Delete All
Refresh

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Dest Port Range</b>	Display the Destination Port Range (Range is from 1 to 65535)
<b>Protocol</b>	Display the protocol that has been chosen by the user.
<b>Comment</b>	Put any notes for the entry.
<b>Select</b>	Select the table, so user can press <b>Delete Selected</b> to delete,
<b>Edit</b>	Click edit to modify the parameters

Click **Refresh** to refresh the table

### 3.7.3 NAT SETTING

**Network Address Translation** is the process where a network device, usually a firewall, assigns a public address to a device or group of devices inside a private network. The main use of NAT is to limit the number of public IP addresses an organization or company must use, for both economic and security purposes. The simple type of NAT provides one to one translation of IP address. It can be used to interconnect two IP networks, normally one network is for Local Area Network and the other network is for Wide Area Network/Internet. To support this function, there are two ways to do it, by using Source Network Address Translation (SNAT), Destination Network Address Translation (DNAT). Basically, Network Address Translation (NAT) occurs when one of the IP addresses in an IP packet header is changed. In a SNAT, the destination IP address is maintained and the source IP address is changed. Most commonly, a SNAT allows a host on the “inside” of the NAT, in an RFC 1918 IP address space, to initiate a connection to a host on the “outside” of the NAT. It supports the Port Forwarding, DMZ and 1 to 1 NAT configuration. A DNAT, by way of contrast, occurs when the destination address is changed and the source IP address is maintained. A DNAT allows a host on the “outside” to connect to a host on the “inside”. In both cases, the NAT has to maintain a connection table which tells the NAT where to route returning packets. An important difference between a SNAT and a DNAT is that a SNAT allows multiple hosts on the “inside” to get to any host on the “outside”. By way of contrast, a DNAT allows any host on the “outside” to get to a single host on the “inside”. It is supported in NAPT and 1 to 1 NAT features. To configure the NAT Setting, the **Port Forwarding, DMZ, Port Mapping Policy and 1 to 1 NAT** configuration page are provided in this section.

#### Port Forwarding

### Port Forwarding

**Port Forwarding**  Enable

**Public Port Range:**  -

**IP Address:**

**Protocol:**

**Port Range:**  -

**Comment:**

Public Port Range	Local IP Address	Protocol	Port Range	Comment	Select	Edit
-------------------	------------------	----------	------------	---------	--------	------

By configuring this table, it allows user to automatically redirect common network services to a specific machine behind the NAT firewall. Select **Enable** to activate **Port Forwarding** function and then input all of the parameters to configure the port forwarding.

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Port Forwarding</b>	Select Enable to activate Port Forwarding function.
<b>Public Port Range</b>	Configure the port range, which will be public to a WAN / Internet. User can configure one or a range of TCP/UDP port number.
<b>IP Address</b>	Configure the IP Address of the LAN PC. The traffic from the public port range will be redirected to this IP address.
<b>Protocol</b>	Configure TCP, UDP or Both (TCP + UDP) protocol type.
<b>Port Range</b>	Configure the port range of the LAN; the traffic from the public port will be redirected to these ports.
<b>Comment</b>	Add information to the entry.

Once User finishes configuring the settings, click on **Submit** to apply User configuration.

## **DMZ**

A **Demilitarized Zone** is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains device accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

**DMZ**

DMZ:  Enable

DMZ Host IP Address:

Click **Enable** to activate the function and assign the IP address of **DMZ Host IP Address**. This is the DMZ computer's IP address. Click Submit to activate the function.

The description of the columns is as below:

TERMS	DESCRIPTION
<b>DMZ</b>	Select Enable to activate DMZ function.
<b>DMZ Host IP Address</b>	Configure the port range, which will be public to a WAN / Internet. User can configure one or a range of TCP/UDP port number.

## **Port Mapping Policy**

This page allows user to configure the Port Mapping policy from NAT Setting.

**Port Mapping Policy**

Port Mapping Policy

The description of the columns is as below:

TERMS	DESCRIPTION
Port Mapping Policy	<p><b>Default: Reuse</b></p> <p>Reuse: Use the same port number that has been used to access the same remote device.</p> <p>Randomize: Change the port number every time access the remote device.</p>

Click **Submit** to apply the configuration.

### 1 to 1 NAT

One-to-one NAT is a way to make systems behind a firewall and configured with private IP addresses (those reserved for private use in RFC 1918) appear to have public IP addresses. With one-to-one NAT, you assign local systems RFC 1918 addresses then establish a one-to-one mapping between those addresses and public IP addresses. For outgoing connections SNAT (Source Network Address Translation) occurs and on incoming connections DNAT (Destination Network Address Translation) occurs. Below is the 1 to 1 NAT section interface.

#### 1 to 1 NAT

1 to 1 NAT  Enable

Local IP Address

WAN IP Address

Comment

Local IP	WAN IP	Comment	Select	Edit
192.168.10.1	192.168.1.1	Main Server	<input type="checkbox"/>	<input type="button" value="Edit"/>

The description of the columns is as below:

TERMS	DESCRIPTION
1 to 1 NAT	Check the box to enable the function
Local IP Address	The target local IP Address
WAN IP Address	The incoming IP Address that coming through the WAN
Comment	Enter a comment

Click **Submit** to apply the configuration.

### 3.7.4 OPEN VPN

WoMaster router supports OpenVPN. It implements virtual private network (VPN) techniques for creating secure point-to-point or site-to-site connections. It is possible to create one-to-many tunnel for the VPN Server. OpenVPN implementation offers a cost-effective, simply configurable alternative to other VPN technologies. OpenVPN allows peers to authenticate each other using a pre-shared secret key, certificates, or username/password. The server and client have almost the same configuration. The difference in the client configuration is the remote endpoint IP or hostname field. Also, the client can set up the keepalive settings.

#### OpenVPN Status

This section shows the VPN Client and Server current status.

Access Control ▾ | Outbound Firewall ▾ | NAT Setting ▾ | OpenVPN ▾ | IPsec Setting

### OpenVPN Status

OpenVPN

**Client Status**

**Enabled**

**Connection Status**

**Server Status**

**Enabled**

[Refresh](#)

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enabled</b>	<b>Default: no</b> <b>yes:</b> The VPN function is enabled. <b>no:</b> The VPN function is not enabled
<b>Connection Status</b>	<b>Default: Disconnected</b> <b>Connected:</b> The VPN connection is established <b>Disconnected:</b> The VPN connection is not established

Click **Refresh** to update the information.

## OpenVPN Client

This page is about the OpenVPN Client configuration page. While the device set as the VPN client, the parameters must follow the VPN Server settings. User should adjust the parameters with the administrator of the VPN server to entry the correct parameters. Two VPN servers IP are also provided in order to have the backup connection for VPN Server.

Access Control ▾
Outbound Firewall ▾
NAT Setting ▾
OpenVPN ▾
IPSec Setting

### OpenVPN Client

**Enable VPN Client :**  Enable

**Encryption Mode :**  Static  TLS

**Server 1 :**  (IP or Domain Name)

**Server 2 :**

**Port :**  (1-65535)

**Tunnel Protocol :**

**Encryption Cipher :**

**Hash Algorithm :**

**ping-timer-rem :**  Enable  Disable

**persist-tun :**  Enable  Disable

**persist-key :**  Enable  Disable

**LZO Compression :**  Enable  Disable

**Keepalive :**  Enable  Disable

**Ping Interval :**  (1-99999 seconds)

**Retry Timeout :**  (1-99999 seconds)

**nobind :**

**ifconfig :** Local :  Remote :

**Route :** IP :  MASK :

**Save Log File :**

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enable VPN Client</b>	Select Enable to activate the VPN Client function
<b>Encryption Mode</b>	Choose the Encryption Mode Static Key: Use a pre-shared static key. TLS: Use SSL/TLS + certificates for authentication and key exchange.
<b>Server 1</b>	Type the IP Address of the VPN Server
<b>Server 2</b>	Type the second IP Address of the VPN Server if needed.

<b>Port</b>	<b>Default: 1194</b> Input the port number that VPN service used. Please check the VPN Server port setting. The range from 1-65535.
<b>Tunnel Protocol</b>	Choose use TCP or UDP to establish the VPN connection.
<b>Encryption Cipher</b>	Select the encryption cipher from Blowfish to AES in Pull-down menus.
<b>Hash Algorithm</b>	Hash algorithm provides a method of quick access to data, including SHA1 , SHA256 , SHA512 , MD5
<b>ping-timer-rem</b>	<b>Default: Enable</b> Select enable or disable the ping-timer-rem, this function prevent unnecessary restart at server/client when network fail.
<b>persist-tun</b>	<b>Default: Enable</b> Select enable or disable the persist-tun, enable this function will keep tun(layer 3) device linkup after Keepalive timeout.
<b>persist-key</b>	<b>Default: Enable</b> Select enable or disable the persist-key, enable this function will keep the key first use if VPN restart after Keepalive timeout.
<b>LZO Compression</b>	<b>Default: Disable</b> Select use LZO Compression or not, this function compresses data to decrease the traffic but also need more CPU effort.
<b>Keepalive</b>	<b>Default: Enable</b> Select enable or disable Keepalive function, this function is use to detect the status of connection.
<b>Ping Interval</b>	<b>Default: 10</b> Input the ping interval, the range can from 1~99999 seconds.
<b>Retry Timeout</b>	<b>Default: 60</b> Input the retry timeout, the range can from 1~99999 seconds.
<b>nobind</b>	Check the box to activate nobind function. With nobind function, the source ports are random.
<b>ifconfig</b>	Input the tunnel IP addresses that VPN use.
<b>Route</b>	Input the route IP and MASK. This is the target IP domain that user can access through the VPN tunnel.
<b>Save Log File</b>	Click Save to keep the VPN Client Log.

Click **Submit** to apply the configuration.

## OpenVPN Server

To help user create the One to One Secure connection for the remote devices, WoMaster device supports both OpenVPN Server and OpenVPN Client. This Server setting allows user to configure the Secure M2M connection for one remote Client. But WoMaster router also supports one to multiple for VPN Client.

Access Control ▾
Outbound Firewall ▾
NAT Setting ▾
OpenVPN ▾
IPSec Setting

### OpenVPN Server

**Enable VPN Server**  Enable

**Encryption Mode :**  Static  TLS

**Port :**  (1-65535)

**Tunnel Protocol :**  ▾

**Encryption Cipher :**  ▾

**Hash Algorithm :**  ▾

**ping-timer-rem :**  Enable  Disable

**persist-tun :**  Enable  Disable

**persist-key :**  Enable  Disable

**Use LZO Compression :**  Enable  Disable

**Keepalive :**  Enable  Disable

**Ping Interval :**  (1-99999 seconds)

**Retry Timeout :**  (1-99999 seconds)

**ifconfig :** Local :  Remote :

**Route :** IP :  MASK :

**Save Log File :**

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enable VPN Server</b>	Select Enable to activate the VPN Server function
<b>Encryption Mode</b>	Choose the Encryption Mode Static Key: Use a pre-shared static key. TLS: Use SSL/TLS + certificates for authentication and key exchange.
<b>Server 1</b>	Type the IP Address of the VPN Server
<b>Server 2</b>	Type the second IP Address of the VPN Server if needed.
<b>Port</b>	<b>Default: 1194</b> Input the port number that VPN service used. Please check the VPN Server port setting. The range from 1-65535.

<b>Tunnel Protocol</b>	Choose use TCP or UDP to establish the VPN connection.
<b>Encryption Cipher</b>	Select the encryption cipher from Blowfish to AES in Pull-down menus.
<b>Hash Algorithm</b>	Hash algorithm provides a method of quick access to data, including SHA1, SHA256, SHA512, and MD5
<b>ping-timer-rem</b>	<b>Default: Enable</b> Select enable or disable the ping-timer-rem, this function is to prevent unnecessary restart at server/client when the network fails.
<b>persist-tun</b>	<b>Default: Enable</b> Select enable or disable the persist-tun, enable this function will keep tun(layer 3) device linkup after Keepalive timeout.
<b>persist-key</b>	<b>Default: Enable</b> Select enable or disable the persist-key, enable this function will keep the key first use if VPN restart after Keepalive timeout.
<b>LZO Compression</b>	<b>Default: Disable</b> Select use LZO Compression or not, this function compresses data to decrease the traffic, but also need more CPU effort.
<b>Keepalive</b>	<b>Default: Enable</b> Select enable or disable Keepalive function, this function is used to detect the status of the connection.
<b>Ping Interval</b>	Input the ping interval, the range can from 1~99999 seconds.
<b>Retry Timeout</b>	Input the retry timeout, the range can from 1~99999 seconds.
<b>ifconfig</b>	Input the tunnel IP addresses that VPN use.
<b>Route</b>	Input the route IP and MASK. This is the target IP domain that user can access through the VPN tunnel.
<b>Save Log File</b>	Click Save to keep the VPN Server Log.

Click **Submit** to apply the configuration.

## OpenVPN Certificate

Using digital certificates for authentication instead of preshared keys in VPNs is considered more secure. In WoMaster' devices, digital certificates are one way of authenticating two peer devices to establish a VPN tunnel.

Access Control ▾Outbound Firewall ▾NAT Setting ▾OpenVPN ▾IPSec Setting

### VPN Key Management

**Delete VPN Key:**

**Upload VPN Key:**  No file chosen

The description of the columns is as below:

TERMS	DESCRIPTION
Delete VPN Key	Delete the selected certificate
Upload VPN Key	Upload a certificate file from a specified file location

### 3.7.5 IPSEC SETTING

Internet Protocol Security (IPsec) is a protocol suite for securing Internet Protocol (IP) communications by authenticating and encrypting each IP packet of a communication session. By configure this configuration page, user allows IPsec tunnels to pass through the router.

Access Control ▾
Outbound Firewall ▾
NAT Setting ▾
OpenVPN ▾
IPSec Setting

#### IPsec Settings

**Enable IPsec**  Enable

**IPsec Status** Disconnected

**Authentication Method :** PSK ▾

**Pre-shared Key :** 12345678 (max. length 25)

**IPsec Cipher Suites :** AES128-SHA1-DH: ▾  
(algorithms for ike and esp proposal)

**Local IP :** 0.0.0.0  
(use 0.0.0.0 when wan is dynamic ip.)

**Local Subnet :** ex : 192.168.10.0/24 (Network/Netmask)


**Remote Host :** 0.0.0.0  
(use 0.0.0.0 if remote is dynamic ip.)

**Remote Subnet :** ex : 192.168.20.0/24 (Network/Netmask)

The description of the columns is as below:


TERMS	DESCRIPTION
<b>Enable IPsec</b>	Select Enable to activate the IPsec function
<b>IPsec Status</b>	Display the IPsec status, whether it is connected or disconnected
<b>Authentication Method</b>	Default: PSK Optional: Pre Shared Key or Certificate
<b>Pre-shared key</b>	<b>Default: 12345678</b> Set the preshared key
<b>IPsec Cipher Suites</b>	<b>Default: AES128-SHA1-DH2</b> Set algorithms for IKE and ESP proposal, choose AES128-SHA1-DH2, DES-SHA1-DH2 and 3DES-SHA1-DH2
<b>Local IP</b>	IP Address of the local side of the tunnel. (Use 0.0.0.0 when WAN is dynamic IP.)
<b>Local Subnet</b>	Set IPsec local protected subnet and subnet mask, i.e. 192.168.1.0/24
<b>Remote Host</b>	<b>Default: 0.0.0.0</b> Set IPsec Remote Host, use the default setting if remote is dynamic IP
<b>Remote Subnet</b>	Set IPsec Remote Protected Subnet/Subnet Netmask

Click **Submit** to apply the configuration.



The topology above is about how the branch office can get the access to the headquarter server. The two laptops are connected to the device using the Ethernet cable.

The laptop at the branch office picks a role as the VPN Client and the laptop at headquarter picks a role as the VPN Server. To get the access to the server the branch office need to connect to the VPN Server. As we can see the connection is established through the LTE connection. In this case, IPsec connection needs to be enabled. See the setting below.



When the connection is enabled, then the IPsec status will directly change to connected status, which means that the connection is established. So that the laptop at the branch office can access the server at headquarter.

### 3.7.6 GRE SETTING

GRE (Generic Routing Encapsulation RFC2784) is a solution for tunneling RFC1812 private address-space traffic over an intermediate TCP/IP network such as the Internet. GRE tunneling does not use encryption it simply encapsulates data and sends it over the WAN port only. This page allows user to set up GRE tunnels and view information about the amount of data transmitted and received.

#### GRE Setting

GRE  Enable

Remote IP Address

Virtual Remote IP Address

Virtual Local IP Address

Virtual Local Subnet Mask

Tunnel Route

(use 0.0.0.0 if route is default route.)

Tunnel Route Subnet Mask

Key

Comment

Remote IP	Virtual Remote IP	Virtual Local IP	Virtual Local Subnet Mask	Route	Route Subnet Mask	Key	Comment	Select	Edit
-----------	-------------------	------------------	---------------------------	-------	-------------------	-----	---------	--------	------

The description of the column is as below:

TERMS	DESCRIPTION
GRE	Check the box to enable the function.
Remote IP Address	Set the remote real IP Address of the GRE Tunnel
Virtual Remote IP Address	Set the remote virtual IP Address of the GRE tunnel.
Virtual Local IP Address	Set the local virtual IP Address of the GRE tunnel.
Virtual Local Subnet Mask	Set the remote virtual Netmask of the GRE tunnel.
Tunnel Route	Route, the default value is 0.0.0.0
Tunnel Route Subnet Mask	Set the subnet mask for the route
Key	Enter the key for the GRE tunnel.
Comment	Enter any comment to describe the configuration.
Select	Select the list on the table, so user can press <b>Edit</b> or <b>Delete Selected</b> to delete.

Click the **Refresh** button to refresh the list.

### 3.7.7 L2TP SETTING

L2TP is a popular choice for remote roaming users for VPN applications since an L2TP client is built in to the Microsoft Windows operating system. In computer networking, Layer 2 Tunneling Protocol (L2TP) is a tunneling protocol used to support virtual private networks (VPNs) or as part of the delivery of services by ISPs. It does not provide any encryption or confidentiality by itself. Rather, it relies on an encryption protocol that it passes within the tunnel to provide privacy. Below is the L2TP Server Setting interface.

### L2TP Server Setting

**L2TP Server**  Enable

**Local IP Address**

**Offered IP Range**  ~

**Authentication Setting**

**Authentication Method**

The description of the column is as below:

TERMS	DESCRIPTION
<b>L2TP Server</b>	Check the box to enable the function.
<b>Local IP Address</b>	The IP Address of the L2TP Server.
<b>Offered IP Range</b>	Offered IP Address range for the L2TP Clients (Maximum 10 clients)
<b>Authentication Method</b>	This section belongs to User Setting section. User can choose authentication using the password authentication protocol (PAP) and challenge handshake authentication protocol (CHAP).

Click the **Submit** button to apply the configuration.

Below is the User Setting for the L2TP Authentication connection.

### User Setting

**User Name**

**Password**

UserName	Password	Select	Edit
womaster	womaster	<input type="checkbox"/>	<input type="button" value="Edit"/>

The description of the column is as below:

TERMS	DESCRIPTION
<b>User Name</b>	Username for L2TP connection
<b>Password</b>	Password for L2TP connection
<b>Select</b>	Select the list on the table, so user can press <b>Edit</b> or <b>Delete Selected</b> to delete.


Click the **Refresh** button to refresh the list.

## 3.8 ROUTING

Layer 3 routing feature is requested since the hosts located in different broadcast domain can't communicate each other. The WoMaster Industrial Router is supported with two routing methods: static routing and dynamic routing. Dynamic routing makes use of RIPv2. The user can choose one routing method or combine the two methods to establish the routing table. In this Routing pages allows users create the Static Route and RIPv2 to do the routing.

### 3.8.1 ROUTE

There are two subdirectories, Static Route and Route Table.



A static route is a route that is created manually by a network administrator. Static routes are typically used in smaller networks. In static routing, the Router's routing table entries are populated manually by a network administrator. The opposite of a static route is a dynamic route. In dynamic routing, the routing table entries are populated with the help of routing protocols.

The major advantages of static routing are reduced routing protocol router overhead and reduced routing protocol network traffic. The major disadvantages of static routing are network changes require manual reconfiguration in routers and network outages cannot be automatically routed around. Also it is difficult to configure static routing in a complex network.

Below is the Static Route section interface.

### Static Route

Destination: 192.0.2.0  
Netmask: 255.255.255.0  
Gateway: 10.0.0.1  
Metric: 0  
Interface: WAN

Destination	Netmask	Gateway	Metric	Interface	Select	Edit
192.0.2.0	255.255.255.0	*	0	WAN	<input type="checkbox"/>	<input type="button" value="Edit"/>

Below figure show the Route Table.

## Route Table

Protocol	Destination	Connected via via	Interface	Status
Static	0.0.0.0/0	192.168.42.1	-	active
Connected	192.168.10.0/24	direct	LAN	active
Connected	192.168.42.0/24	direct	-	active

Refresh

The description of the column is as below:

TERMS	DESCRIPTION
<b>Destination</b>	The Destination network IP address. For example,192.168.10.0
<b>Netmask</b>	Destination network's subnet mask.
<b>Gateway</b>	Gateway. Factory default is blank (0.0.0.0).
<b>Metric</b>	Assigns a cost to each available route so that the most cost-effective path can be.
<b>Interface</b>	The outgoing network interface. LAN, WAN, and Cellular are available to setup here.
<b>Select</b>	Select the list on the table, so user can press <b>Edit</b> or <b>Delete Selected</b> to delete.
<b>Route Table</b>	The table shows the configured Static Route entry or the Connected Route entries. You can view the destination IP network/Subnet Mask, connected IP address and its status. You can view the connected route entries. It indicates the destination IP network/ Subnet Mask, direct connect or learnt, and its current status.

Click the **Refresh** button to refresh the list.

### 3.8.2 RIP

WoMaster Industrial Router is supported with RIPv2. The Routing Information Protocol (RIP) is a distance-vector, interior gateway (IGP) routing protocol used by routers to exchange routing information. RIP uses the hop count as a routing metric. RIP prevents routing loops by implementing a limit on the number of hops allowed in a path from the source to a destination. The maximum number of hops allowed for RIP is 15. This hop limit, however, also limits the size of networks that RIP can support. RIP version 2 (RIPv2) was developed due to the deficiencies of the original RIP.

#### RIP Configuration

Route ▾ **RIP** OSPF ▾

### RIP Configuration

Enable RIP Protocol **Submit**

Network Address

Netmask

**Submit** **Cancel**

### Routing For Network Status

Network Address	Netmask	Select	Edit
		<input type="checkbox"/>	<b>Edit</b>

**Delete Selected** **Delete All** **Refresh**

The description of the column is as below:

TERMS	DESCRIPTION
Enable RIP Protocol	<b>Submit</b> button to apply RIP protocol setting.
Routing for Networks	All the networks no matter directly connected or learned from other router/switch should be added to the switch. After typing the network address and netmask, click the <b>Submit</b> to add a routing network.

Click the **Submit** button to add a routing network.

Click the **Delete Selected** button to remove selected network address. Click the **Delete All** button to remove all network address. Click the **Refresh** button to refresh RIP information.

### Interface Configuration

### Interface Configuration

Interface	Send Version	Receive Version
LAN ▾	2 ▾	Both ▾

**Submit** **Cancel**

### Interface Status

Interface	Send Version	Receive Version	Select	Edit
WAN	2	1, 2	<input type="checkbox"/>	<b>Edit</b>
LAN	2	1, 2	<input type="checkbox"/>	<b>Edit</b>

**Delete Selected** **Delete All** **Refresh**

TERMS	DESCRIPTION
Interface	The IP interface, LAN or WAN
Send Version	Send version of the target interface, you can select RIPv1 or RIPv2.

<b>Receive Version</b>	Receive version of the target interface, you can select RIPv1, RIPv2 or Both
------------------------	------------------------------------------------------------------------------

Click the **Submit** button to apply RIP interface settings.

Click the **Delete Selected** button to remove selected interface. Click the **Delete All** button to remove all network address. Click the **Refresh** button to reload RIP interface configuration.

### 3.8.3 OSPF

Open Shortest Path First is a link-state protocol that equips the IP, mask, the type of network, the routers connected to that network. The State is its relationship to its neighboring routers. The Metric is the distance between the 2 links; it is usually the bandwidth of the link in link-state protocol. The Link State Database is the collection of all these link states. The destination network address, the shortest metric to the network and the IP address of the next hop are specified in the link state database. It propagates link-state advertisements (LSAs) to its neighbor switches. When compared with RIP (Routing Information Protocol) which is a distance-vector based routing protocol, OSPF can provide scalable network support and faster convergence time for network routing state. OSPF is widely used in large networks such as ISP (Internet Service Provider) backbone and enterprise networks.

The OSPF is a complex protocol which defines the role of the router/switch when it is installed in different Areas. The Area is a group of routers, the OSPF uses flooding to exchange link-state updates between routers. The routers within the same area update its routing table. Any change in routing information is flooded to all routers in the same area.

WoMaster Layer3 Managed Switch design comforts to the OSPF Version 2 specification. Typically, the switch acts as the Internal Router, a router within the area; the Designated Router, the Master router in the same broadcast domain within the area; the Area Board Router which is the boundary router between different area. While configuring the OSPF network, the area ID should be configured with the same IP address or the same area ID.

#### OSPF Setting

**OSPF Setting**

OSPF Protocol Disable ▼

Router ID

**Submit**

**Routing for Networks**

Network Address   (A.B.C.D/M) Area

**Add**

Index	Network Address	Area
	<input type="text"/>	<input type="text"/>

**Remove Selected** **Reload**

**OSPF redistribute option**

Redistribute Type connected ▼ Metric Value  Metric Type none ▼

**Add**

Redistribute Type	Metric Value	Metric Type
	<input type="text"/>	<input type="text"/>

**Remove Selected** **Reload**

TERMS	DESCRIPTION
<b>OSPF Protocol</b>	<b>Enable</b> or <b>Disable</b> the OSPF routing protocol.
<b>Router ID</b>	The router ID can be any IP address, however, the IP address of the existed local interface is suggested. With such IP address, you can find the router/switch easier.  Router ID is used while connected multiple OSPF routers/switches to the same broadcast domain, the lowest Router ID will be selected as the Designated Router in the network.
<b>Routing for Network</b>	Type the <b>Network Address</b> and the <b>Area ID</b> in the field.

Click **Add** to apply the setting then the new entry will appear in the network table below. Click the **Remove** Selected button to remove the selected network. Click the **Reload** button to reload the table.

**NOTE:** All the Area ID of the router/switch within the same area should use the same IP address or ID. All the network address should be added.

### OSPF Interface Setting

**OSPF Interface Setting**

Interface	Area	Cost	Priority	Transmit Delay	Hello	Dead	Retransmit
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

TERMS	DESCRIPTION
<b>Interface</b>	The VLAN Interface name.
<b>Area</b>	The area ID of the Interface you added. The Area ID must be the same for all routers/switches on a network.
<b>Cost</b>	The distance of this link/Interface, the default is identified depends on what the bandwidth is by the system. The value can be changed to decide the best router.
<b>Priority</b>	The priority of this link/Interface. Set priority to help find the OSPF designated router for a network. The default is 1. The range is 0 to 255.
<b>Transmit Delay</b>	The transmit delay timer of this link/Interface. Transmit Delay is the estimated number of seconds to wait before sending a link state update packet. The default value is 1 second.
<b>Hello</b>	The Hello timer of this link/Interface. The value must be the same for all routers/switches on a network. The default value is 10 seconds. The min. value is 1.
<b>Dead</b>	The Dead Interval Timer of this link/Interface. The Dead timer is the time to identify whether the interface is down or not before the neighbors declare the

	OSPF router to be down. The default value is 4 times (40 seconds) than the Hello interval (default is 10).
<b>Retransmit</b>	The count of Retransmit of this link/Interface. The Retransmit time specifies the number of seconds between link state advertisement transmissions. The default value is 5 seconds.

Once finish configuring the settings, click on **Apply** to apply configuration.

### OSPF Area Setting

This page allows user to configure the OSPF Area information. An OSPF domain is divided into different areas. Areas are logical grouping of hosts and networks, including their routers having interfaces connected to any of the included networks. Each area maintains its own link state database. In OSPF, all areas must be connected to a

#### OSPF Area Setting

**OSPF Area Table**

Area	Default Cost	Shortcut	Stub
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

**OSPF Range Table**

Area	Range (A.B.C.D/M)
<input type="text"/>	<input type="text"/>

Area	Range
<input type="text"/>	<input type="text"/>

**OSPF Virtual Link Table**

Area	Virtual Link (A.B.C.D)
<input type="text"/>	<input type="text"/>

Area	Virtual Link
<input type="text"/>	<input type="text"/>

backbone area. The backbone area is responsible for distributing routing information between non-backbone areas. The WoMaster Switch is usually installed as internal router of a single Area environment. While there are multiple areas in the network, this page allows modify the Area information and Virtual Link.

TERMS	DESCRIPTION
<b>Area</b>	This field indicates the area ID. Select the ID you want to modify here.
<b>Default Cost</b>	The default cost of the area ID.
<b>Shortcut</b>	No Defined, Disable, Enable. This indicates whether the area is the OSPF ABR shortcut mode.

<b>Stub</b>	Represents whether the specified Area is a stub area or not. The possible values are No Defined, No Summary and Summary. Summary is used to advertise summary routes.
-------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------

Click the **Apply** button to apply OSPF area settings. Click the **Remove Selected** button to remove selected area.  
 Click the **Reload** button to reload OSPF area configurations.

**OSPF Neighbor Table**

This page allows user to see the OSPF Neighbor information. The Neighbor interface and its state will be listed here.

OSPF Neighbor Table					
Neighbor ID	Priority	State	Dead Time	IP Address	Interface

[Reload](#)

TERMS	DESCRIPTION
<b>Neighbor ID</b>	Display the Router ID of the Neighbor routers/switches.
<b>Priority</b>	Show the priority of the link.
<b>State</b>	While the <b>State</b> is changed to <b>Full</b> , which means the exchange progress is done.
<b>Dead Time</b>	The activated time of the link.
<b>IP Address</b>	Shows the learnt IP interface of the next hops.
<b>Interface</b>	Shows the connected local interface.

Click **Reload** to update the information from the table.

**OSPF Database**

OSPF Database
OSPF Routing Process not enabled

[Reload](#)

Click **Reload** to update the information.

## 3.9 WARNING

WoMaster' router provides several types of Warning feature for remote monitoring of end devices status or network changes.

### 3.9.1 EMAIL ALERT

WoMaster router supports E-mail Warning feature. With this function being enabled, the user is allowed to configure the detail settings for sending the e-mail alert to the SMTP server when the events occur. This page allows User to enable E-mail Alert, assign the SMTP Server IP, Sender E-mail, and Receiver E-mail. If the SMTP server requests User to authorize first, User can also setup the username and password on this page.

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Email Alert</b>	Check the to enable the function
<b>SMTP Server IP Address</b>	Enter the IP address of the Email Server
<b>Email Account</b>	Enter the Email Server Account
<b>Authentication</b>	Choose the Authentication mode (None, Plain, Login)
<b>User Name</b>	Enter email Account name (Max.40 characters)
<b>Password</b>	Enter the password of the email account
<b>Confirm Password</b>	Re-type the password of the email account
<b>User can set up to 2 email addresses to receive email alarm from the router</b>	
<b>Email 1 To</b>	The first email address to receive an email alert from the router (Max. 40 characters)
<b>Email 2 To</b>	The second email address to receive an email alert from the router (Max. 40 characters)

Once User finishes configuring the settings, click on **Submit** to apply the User configuration.

### 3.9.2 PING WATCHDOG

Email Alert
Ping Watchdog
Syslog Setting
Relay Output
Event Type
SNMP ▾

#### Ping Watchdog

Enable Ping IP Address 1

0.0.0.0

Enable Ping IP Address 2

0.0.0.0

Ping Interval

300

seconds

Watchdog Deferred

120

seconds(>120)

Ping Fail Counter

30

Submit
Cancel

Ping Watchdog is a feature that helps WoMaster' router to allow user continuously ping a specific remote host for connection status using a user-defined IP address (or an Internet gateway). In this section, WoMaster provides two target IP Addresses, in order if the other IP Address cannot be reached, so there is another backup IP address. There are two conditions in this Ping Watchdog section, the first one is when the device continuously ping the target IP and in the end, it can reach one of the target IPs the device would not reboot. But if both targets IPs cannot be reached, the device will start counting the Ping Fail Counter time till it can be reached. If it is unable to ping the target IP address, this device will automatically reboot. After User finishes configuring the settings, click on **Submit** to apply User configuration.

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enable Ping IP Address 1</b>	Clicks enable to activate the feature. Set the first IP Address to check if the device is alive or not
<b>Enable Ping IP Address 2</b>	Clicks enable to activate the feature. Set the second IP Address to check if the device is alive or not
<b>Ping Interval</b>	<b>Default: 300 (seconds)</b> Set the interval timer to Ping the remote device. Every 300 seconds the device will try to ping the target IP.
<b>Watchdog Deferred</b>	<b>Default: 120 (seconds) &gt;120</b> The device needs time to boot, the startup delay use to buffer to prevent the device continue to reboot itself.
<b>Ping Fail Counter</b>	<b>Default: 30</b> When the remaining Ping Fail Counter reach to 0 or reach the failure count, the device will reboot.

Click **Submit** to apply the configuration.

### 3.9.3 SYSLOG SETTING

System Log is useful to provide system administrator locally or remotely monitor router events history.

[Email Alert](#) | [Ping Watchdog](#) | **[Syslog Setting](#)** | [Relay Output](#) | [Event Type](#) | [SNMP](#) ▾

### System Log

**Enable Remote Syslog Server**

**IP Address:**

**Port:**

Once User finishes configuring the settings, click on **Submit** to apply User configuration. User can monitor the system logs in [Diagnostics] / [Event Log] page

The condition or term described as following table.

TERMS	DESCRIPTION
<b>Enable Remote Syslog Server</b>	Select Enable to enable system log
<b>IP Address</b>	Specify the IP address of the server.
<b>Port</b>	<b>Default: 514</b> Specify the port number of the server

After finish with the configuration, clicks **Submit** to activate the function.

### 3.9.4 RELAY OUTPUT

WoMaster' router provides 1 alarm relay output, also known as Digital Output. These settings in Relay Output section control the events that will trigger the alarm output. The Relay Output configuration interface has shown as below:

The condition or term described as following table.

TERMS	CONDITION	DESCRIPTION
Relay	ON or OFF	The status change to ON if any kind of failure is detected. OFF if the status is normal.
Link Failure	LAN Port number 1 - 5	Monitoring port link down event
DI 1/2/3	Specify DI status	Relay alarm based on the DI status change. <b>Note:</b> Only supported in the model with DI functionality.

After finishing the configuration, clicks **Submit** to activate the relay alarm function.

### 3.9.5 EVENT TYPE

In this page user allowed to select the Event Type **Event Warning Type**: The event warning type selection. It has two event types, Authentication Failure and Configuration Changed.

TERMS	DESCRIPTION
Authentication Failure	When the authentication fails, the system will issue the event log/email alert to the system log/SMTP server respectively.
Configuration Changed	When there are any kinds of changing in the configuration, the system will issue the event log/email alert to the system log/SMTP server respectively.

Click **Submit** to apply the configuration.

### 3.9.6 SNMP

SNMP is a standard TCP/IP protocol for network management. Network administrators use SNMP to monitor and map network availability, performance, and error rates. System management software uses SNMP to allow administrators to remotely monitor and manage thousands of systems on a network, often by presenting the data gathered from monitored devices in a snapshot or dashboard view. WoMaster' Router support SNMP V2c and V3

#### SNMP Settings

**Enable SNMP**  Enable

**Protocol Version** V2c

**Server Port** 161

**Get Community** .....

**Set Community** .....

#### SNMP Trap Server

**SNMP Trap**  Enable

**Trap Server** 0.0.0.0

**Trap Community** .....

**Submit** **Cancel**

#### SNMP Setting

In this page, user may configure the SNMP setting, click enable to activate the function. Select the Protocol version (V2c/V3), configure the server port, set up the password for the Get Community and specify the password for Set Community.

#### SNMPv2C

SNMPv2c is a sub-version of SNMPv2. Its key advantage over previous versions is the Inform command. Unlike Traps, which are simply received by a manager, Informs are positively acknowledged with a response message. If a manager does not reply to an Inform, the SNMP agent will resend the Inform.


#### SNMP V3

SNMPv3 is the newest version of SNMP. Its primary feature is enhanced security.

SNMPv3 security comes primarily in 2 forms:

- **Authentication** is used to ensure that traps are read by only the intended recipient.
- **Privacy** encrypts the payload of the SNMP message to ensure that it cannot be read by unauthorized users.

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enable SNMP</b>	Click the box to enable the SNMP function.
<b>Protocol Version</b>	<p><b>Default: V2c</b> Select the SNMP protocol version.</p> 
<b>Server Port</b>	<p><b>Default: 161</b> Sets the port on which SNMP data has been sent. User can specify port by marking on user defined and specify port that user wants SNMP data to be sent.</p>
<b>Get Community</b>	<p><b>Default: public</b> Create the name for a group or community of administrators who can view SNMP data. For security reasons, any numbers you enter will not be displayed in plain text.</p>
<b>Set Community</b>	<p><b>Default: private</b> Create the name for a group or community of administrators who can write or edit SNMP data. For security reasons, any numbers you enter will not be displayed in plain text.</p>

After finishing the configuration, clicks **Submit** to activate the function.

### SNMP Trap Server

SNMP trap is the most frequently used SNMP messages. These messages are sent to the manager by an agent when an issue needs to be reported. SNMP traps are quite unique if compared to other message types, since they are the only method that can be directly initiated by an SNMP agent. The other types of messages are either initiated by the SNMP manager or sent as a result of the manager's request. This ability makes SNMP traps indispensable in most networks. It is the most convenient way for an SNMP agent to inform the manager that something wrong is going on.

The description of the columns is as below:

TERMS	DESCRIPTION
<b>SNMP Trap</b>	Clicks enable to activate the function. All of events that associated with the device will be sent to the server in real time, and can be seen by remote clients
<b>Trap Server</b>	<p><b>Default: 0.0.0.0</b> Set the IP Address of the trap server where to report the events.</p>
<b>Trap Community</b>	<p><b>Default: public</b> Create the name for a group or community of administrators who can allow reporting the events. If the group is match then the events can be reported. For security reasons, any numbers you enter will not be displayed in plain text.</p>

After finish with the configuration, clicks **Submit** to activate the function.

## SNMP V3

SNMP v3 can provide more security functions when the user performs remote management through SNMP protocol. This field displays the SNMPv3 configuration page for Admin and User. If the value from Access Type is set to **Read-Write**, the SNMPv3 user will be able to set and retrieve parameters on the system. And if the value is set to **Read Only**, the SNMPv3 user will only be able to retrieve parameter information. It delivers SNMP information to the administrator with user authentication; all of data between the router and the administrator are encrypted to ensure secure communication. SNMPv3 requires an authentication level of MD5 or DES to encrypt data to enhance data security. To activate the page make sure user has already chosen SNMPv3 at the SNMP Setting page.

Email Alert	Ping Watchdog	Syslog Setting	Relay Output	Event Type	SNMP ▾
<b>SNMP V3</b>					
<b>SNMPv3 Admin</b>		<input checked="" type="checkbox"/> <b>Enable</b>			
<b>Admin User Name:</b>	<input type="text" value="SNMPv3Admin"/>				
<b>Admin Password:</b>	<input type="password"/>				
<b>Confirm Password:</b>	<input type="password"/>				
<b>Access Type:</b>	Read/Write ▾				
<b>Authentication Protocol:</b>	MD5 ▾				
<b>Privacy Protocol:</b>	None ▾				
<b>SNMPv3 User</b>		<input checked="" type="checkbox"/> <b>Enable</b>			
<b>User Name:</b>	<input type="text" value="SNMPv3User"/>				
<b>Password:</b>	<input type="password"/>				
<b>Confirm Password:</b>	<input type="password"/>				
<b>Access Type:</b>	Read Only ▾				
<b>Authentication Protocol:</b>	MD5 ▾				
<b>Privacy Protocol :</b>	None ▾				

TERMS	DESCRIPTION
<b>SNMPv3 Admin</b>	Clicks enable to activate the function and the entries for SNMPv3 Admin.
<b>Admin User Name</b>	<b>Default: SNMPv3Admin</b> Set up the User Name for the SNMPv3 Admin
<b>Admin Password</b>	Set up the Password for the SNMPv3 Admin
<b>Confirm Password</b>	Confirm the Admin for the SNMPv3 Admin
<b>Access Type</b>	Access type for the SNMPv3 Admin, choose Read Only or Read and Write
<b>Authentication Protocol</b>	<b>Default: MD5</b> Provides authentication based on MD5 or SHA algorithms.
<b>Privacy Protocol</b>	Specify the encryption method for SNMP communication. None and DES are available. <b>None:</b> No encryption is applied.

	<b>DES:</b> Data Encryption Standard, it applies a 58-bit key to each 64-bit block of data.
<b>SNMPv3 User</b>	Clicks enable to activate the function and the entries for SNMPv3 User
<b>User Name</b>	<b>Default: SNMPv3User</b> Set up the User Name for the SNMPv3 User
<b>Password</b>	Set up the Password for the SNMPv3 User
<b>Confirm Password</b>	Confirm the Admin for the SNMPv3 User
<b>Access Type</b>	Access type for the SNMPv3 User, choose Read Only or Read and Write
<b>Authentication Protocol</b>	<b>Default: MD5</b> Provides authentication based on MD5 or SHA algorithms.
<b>Privacy Protocol</b>	Specify the encryption method for SNMP communication. None and DES are available.  <b>None:</b> No encryption is applied.  <b>DES:</b> Data Encryption Standard, it applies a 58-bit key to each 64-bit block of data.

### 3.9.7 PERIODIC REBOOT

The setting allows you reboot the device in case some un-controller error in remote site. This is one type of the watchdog feature, **it is better to configure longer period, and please Notice that the router will periodically reboot the router even the router works normally.** The period is configurable, allowing at Daily Reboot Time or specific time of periodic resets.

#### Periodic Reboot Settings

Disable  
 Daily Reboot Time   
 Periodic Reboot Hour(s)

- 1 hour
- 5 hours
- 6 hours
- 7 hours
- 8 hours
- 9 hours
- 10 hours
- 11 hours
- 12 hours
- 13 hours
- 14 hours
- 15 hours
- 16 hours
- 17 hours
- 18 hours
- 19 hours
- 20 hours
- 21 hours
- 22 hours
- 23 hours
- 24 hours

TERMS	DESCRIPTION
<b>Disable</b>	Disable the feature
<b>Daily Reboot Time</b>	Type the specific daily reboot hour time of hour/minute. The format is HH:MM, ex: 23:00
<b>Periodic Reboot Hour(s)</b>	Select the period time you prefer in this column.

## 3.10 DIAGNOSTICS

WoMaster Router provides several types of features for User to monitor the status of the router or diagnostic for User to check the problem when encountering problems related to the router.

Following commands are included in this group:

3.10.1 Event Logs

3.10.2 ARP Table

3.10.3 Ping

3.10.4 Trace Route

3.10.5 Network Statistic

### 3.10.1 EVENT LOGS

When remote System Log server mode is activated, the router will record occurred events in local log table. This page shows this log table. The entry includes the index, occurred data, time and content of the events.

Event Logs	ARP Table	Ping	Network Statistics
620	2018-03-02 14:37:40	cellular	Reboot Cellular Module ..
627	2018-03-02 14:38:23	cellular	Cellular starts to connect!
628	2018-03-02 14:38:43	cellular	Reboot Cellular Module ..
629	2018-03-02 14:39:26	cellular	Cellular starts to connect!
630	2018-03-02 14:39:46	cellular	Reboot Cellular Module ..
631	2018-03-02 14:40:29	cellular	Cellular starts to connect!
632	2018-03-02 14:40:49	cellular	Reboot Cellular Module ..
633	2018-03-02 14:41:32	cellular	Cellular starts to connect!
634	2018-03-02 14:41:52	cellular	Reboot Cellular Module ..
635	2018-03-02 14:42:35	cellular	Cellular starts to connect!
636	2018-03-02 14:42:55	cellular	Reboot Cellular Module ..
637	2018-03-02 14:43:38	cellular	Cellular starts to connect!
638	2018-03-02 14:43:58	cellular	Reboot Cellular Module ..

Reload Clear Download

TERMS	DESCRIPTION
#	Event index assigned to identify the event sequence.
Time	The time is updated based on how the current date and time is set in the Basic Setting page.
Source	Show the log's source.
Message	Show the record status.

Click **Reload** to refresh the table. Click **Clear** to remove the entire event logs list. User may download the event logs file by click **Download**.

### 3.10.2 ARP TABLE

Basically, WoMaster device is supported with two types of ARP which is the standard ARP and ARP with 802.2 LLC Type 2. Address Resolution Protocol (ARP) is a protocol for mapping an Internet Protocol address (IP address) to a physical machine address that is recognized in the local network. A table, usually called the ARP cache, is used to maintain a correlation between each MAC address and its corresponding IP address. ARP provides the protocol rules for making this correlation and providing address conversion in both directions. The other ARP feature is ARP with 802.2 LLC Type 2 is the new level of ARP where the device will response the request of 802.2 snap ARP on the Ethernet port and not support sending the request of 802.2 snap ARP. Below is the Data format.

#### Data Format

Protocol Header:

802.3 + 802.2 LLC + 802.2 snap

| - (DS + SA + Len) - | - DSAP + SSAP + CTRL - | - Org + type


This page shows the routers active ARP table. An ARP table contains recently cached MAC addresses of every immediate device that was communicating with the router.

Event Logs	<b>ARP Table</b>	Ping	Network Statistics
<b>ARP Table</b>			
IP Address	MAC Address	Interface	
192.168.10.80	70:8b:cd:03:b5:67	br0	
<b>Reload</b>			

Click on **Reload** to change the value.

### 3.10.3 PING

WoMaster' provides **Ping** utility in the management interface, the function is to give users a simple but powerful tool for troubleshooting network problems and check that the remote device is still alive or not. Type **Destination IP** address of the target device and click on **Ping** to start the ping.




```
PING 192.168.10.80 (192.168.10.80): 66 data bytes
64 bytes from 192.168.10.80: icmp_seq=0 ttl=128 time=0.2 ms
64 bytes from 192.168.10.80: icmp_seq=1 ttl=128 time=0.3 ms
64 bytes from 192.168.10.80: icmp_seq=2 ttl=128 time=0.3 ms
64 bytes from 192.168.10.80: icmp_seq=3 ttl=128 time=0.2 ms

--- 192.168.10.80 ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 0.2/0.2/0.3 ms
```

### 3.10.4 TRACE ROUTE


Traceroute is a diagnostics tool for displaying the route (path) and measuring transit delays of packets across an Internet IP network. Log containing route information will be shown after few seconds. Enter the destination IP Address then click traceroute to start the process.



It will start search the route and measuring the transit delays of the packet.



```
Trace route for 192.168.10.100
1 192.168.10.100 (192.168.10.100) 1.136 ms
```



```
Trace route for 192.168.10.100
1 192.168.10.100 (192.168.10.100) 1.136 ms + 0.77 ms
```

### 3.10.5 NETWORK STATISTICS

This section shows about the packet data that transmitted or received regarding the Ethernet and Cellular activity. The Cellular packets include Wi-Fi and 2G/3G/LTE transmission.

Event Logs
ARP Table
Ping
Network Statistics

## Network Statistics

Refresh Period  (0-65534) sec Set Stop

	Received	Transmitted
<b>WLAN 1 1</b>		
<i>Unicast Packets</i>	0	0
<i>Error Packets</i>	0	10
<i>Dropped Packets</i>	0	0
<i>Packet Count</i>	0	10
<i>Byte Count</i>	0	0
<b>Ethernet 1</b>		
<i>Packet Count</i>	2	2832
<i>Byte Count</i>	128	531395
<b>Ethernet 2</b>		
<i>Packet Count</i>	2210	1840
<i>Byte Count</i>	526417	622963
<b>Cellular</b>		
<i>Packet Count</i>	0	0
<i>Byte Count</i>	0	0

Reload

Click on **Reload** to refresh the table.


The description of the columns is as below:

TERMS	DESCRIPTION
<b>Poll Interval</b>	<b>Default: 5</b> To set the Poll Interval time setting with range from 0 to 65534. (second)
<b>Set</b>	To set new Interval time. Stop the old Poll Interval first before set the new interval.
<b>Stop</b>	To stop Polling Interval, this action can be executed when user wants to change the poll interval time.


### 3.10.6 DYING GASP

A dying gasp is a message sent by the router to indicate that the router has lost power. It's also known as "last gasp". The dying gasp is enabled in the router which supports dying gasp hardware and software feature. To see the dying gasp, you MUST configure the target Syslog Server or SNMP Trap server. Then it has possibility of sending a last gasp event to the specific server while power supply loss.

Below figures show the example of SNMP trap and syslog events.



SNMP Trap



syslog

### 3.11 IoT

Over the past decade or so, the word “cloud” has taken on a new meaning to many people. Rather than a visible mass of condensed water vapor floating in the sky, the cloud has taken to the IoT industry in the form of data. WoMaster Industrial Router is supported with private clouds, ThingsMaster and public clouds, AWS and Microsoft Azure. Clouds offer great promise in improving the agility and flexibility of IT to respond to the requirements of the business cost effectively. The security challenges raised by the loss of control and visibility in the journey to the cloud can be addressed in terms of securing infrastructure, information, identities, and devices.

#### 3.11.1 AWS IoT

Amazon Web Services IoT enables secure, bi-directional communication between Internet-connected things (such as sensors, actuators, embedded devices, or smart appliances) and the AWS cloud over MQTT and HTTP. For more information please visit: <http://aws.amazon.com/iot/>.

#### AWS IoT

Enable	<input checked="" type="checkbox"/>		
AWS Root CA	Load		<input type="button" value="Delete"/>
AWS Certificate file	Load		<input type="button" value="Delete"/>
AWS Private Key file	Load		<input type="button" value="Delete"/>
Target Host	<input type="text" value="a279rf4cdqyuy8.iot.us-west-2.amazonaws.com"/>		
Port	<input type="text" value="443"/>		
Client ID	<input type="text" value="WR322"/>		
My Thing Name	<input type="text" value="WR322"/>		


The description of the columns is as below:

TERMS	DESCRIPTION
Enable	Enable the AWS IoT function
AWS Root CA	Root CA is necessary. User can download it from the AWS.
AWS Certificate file	Certificate is necessary. User can download it from the AWS.
AWS Private Key file	Private key is necessary. User can download it from the AWS.
Target Host	Enter the target host
Port	<b>Default: 433</b> Because AWS uses the HTTPS traffic, user need to add an inbound rule on port 443
Client ID	Enter the device client ID
My Thing Name	Enter the registered device name (Need to be the same)


Click **Submit** to apply the configuration.

## HOW TO CONNECT THE DEVICE TO AWS

- Create and login to AWS account.
- Select AWS IoT Services – click Thing.
- Add your device shadow.




- Create and download the key or certificate.



Certificate, private key, root CA is necessary. Public key is used by AWS server to authenticate with private key. The public key and private cannot be downloaded back after the user closes the page. Policy can be added later.

- Get the Target host to connect with the device.  
Go to Manage -> Things -> click the device name -> Click Interact.  
Copy the HTTPS link to update user's Thing Shadow using this Rest API Endpoint.



- Connect the device to AWS.  
Copy the link and paste on the Target Host field at the AWS IoT page.

### AWS IoT

<b>Enable</b>	<input checked="" type="checkbox"/>	
<b>Target Host</b>	<input type="text" value="a279rf4cdqyuy8.iot.us-west-2.amazoniaw"/>	
<b>Port</b>	<input type="text" value="443"/>	
<b>Client ID</b>	<input type="text" value="SCB1000-0002"/>	
<b>My Thing Name</b>	<input type="text" value="SCB1000-0002"/>	
<b>AWS Root CA</b>	<span>Load</span>	<span>Delete</span>
<b>AWS Certificate file</b>	<span>Load</span>	<span>Delete</span>
<b>AWS Private Key file</b>	<span>Load</span>	<span>Delete</span>

Submit Cancel

### 3.11.2 AZURE IoT

Azure IoT Hub is a fully managed service that enables reliable and secure bi-directional communications between millions of Internet of Things (IoT) devices and a solution back end. One of the biggest challenges that IoT projects face is how to reliably and securely connect devices to the solution back end. To address this challenge, IoT Hub:

- Offers reliable device-to-cloud and cloud-to-device hyper-scale messaging.
- Enables secure communications using per-device security credentials and access control.
- Includes the most popular communication protocols.

**Azure IoT**

Enable

Root CA Load Delete

IoT Hub

Port

Client ID

SAS Token

Submit Cancel

The description of the columns is as below:

TERMS	DESCRIPTION
Enable	Enable Azure IoT function
Root CA	Download and enter the root CA.
IoT Hub	Enter the IoT hub server, this information can be found at the azure platform
Port	<b>Default: 8883</b> Display the port number. Because Azure IoT uses the MQTT protocol, so user needs to enter 8883 port number that belongs to MQTT protocol.
Client ID	Enter the client ID
SAS Token	Enter the SAS Token that needs to be generated by software. (Azure Device Explorer)

Click **Submit** to apply the configuration.

## HOW TO CONNECT THE DEVICE TO MICROSOFT AZURE

### CREATE IOT HUB

To register the device in Azure Portal, user has to follow the guide “Get started with Azure IoT Hub for Java”: <https://azure.microsoft.com/en-us/documentation/articles/iot-hub-java-java-getstarted/>.

The guide explains how to create an IoT Hub and a device entity. It is important to annotate the connection string generated after creating the device entity. User will need this parameter later for the device configuration (WoM IoT Configuration).


## CONFIGURE THE DEVICE AS A MQTT CLIENT

In the Microsoft Azure Portal, go to IoT Hub menu and select:


Devices > myCreatedDevice > Shared access policies > iothubowner > Connection string - primary key.

User has to annotate the value of this field.


1. Get the connection string. Click the IoT Hub -> Shared access policies.




2. Click registryReadWrite -> copy the Connection string---Primary Key.



3. Download and install the Azure Device Explorer to generate the SAS Token. Go to this link to download the software: <https://github.com/Azure/azure-iot-sdk-csharp/releases/download/2018-3-13/SetupDeviceExplorer.msi>



4. Paste the Connection String --- Primary Key to the IoT Hub Connection String box. Then type the Protocol Gateway HostName and click Update. In the end, generate the SAS Token.



5. Configure the MQTT Client from the Web GUI. Enter the value based on the IoT Hub setting. And the device is connected to the cloud.

**Azure IoT**

Enable

IoT Hub

Port

Client ID

SAS Token

Root CA

Please find the Root CA through this link: <https://github.com/Azure/azure-iot-sdk-c/blob/master/certs/certs.c>

### 3.11.3 PRIVATE IoT

WoMaster provides its private cloud service, ThingsMaster that could support the Industrial Plants Network. Under the cloud architecture, software, hardware, applications, and storage can all be provided as services. The cloud network service has the advantages of easy expansion, rapid adjustment, and minimal management, and can dynamically meet increasing demands. Users can access the data which stored on the cloud anywhere, anytime, and seamlessly share to any authorized users.

Home > IoT > Private IoT

AWS IoT Azure IoT Private IoT CoAP Modbus Device RMS/OTA

**Private IoT**

Enable

Connection Status Disconnected

IoT Server

Port

Username

Password

Client ID

MQTT Publish Topic

MQTT Publish Interval  seconds

Update on change

CA Certificate  未選擇任何檔案

Debug Mode

Debug Log

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enable</b>	Enable the WoM IoT function
<b>Connection Status</b>	The connection status between the router and IoT server.
<b>IoT Server</b>	Enter the specific IoT Server.
<b>Port</b>	Specify the specific port of the IoT server.
<b>User Name</b>	Enter the user name.
<b>Password</b>	Enter the password of the user name.
<b>Client ID</b>	Enter the client ID that has been registered.
<b>MQTT Publish Topic</b>	Specify the MQTT Topic
<b>MQTT Publish Interval</b>	The interval time to update the data.
<b>Update on change</b>	<p><b>Default: Uncheck</b></p> <p>Check the box to keep update the data. The router will check whether the system and Modbus info from serial port is updated or not, if the value is changed, the router will publish the data to IoT Server.</p>
<b>CA Certificate</b>	<p>The function from this certificate file is to create an encrypted MQTT communication. User can apply the CA file from the cloud server. For example, you can get this file together when download the ThingsMaster server file.</p> <p><b>Note. This field only supports in ThingsMaster v1.1</b></p>
<b>Debug Mode</b>	Enable/Disable the debug mode. Default is Uncheck.
<b>Debug Log</b>	You can download the log for debugging.

Click **Submit** to apply the configuration.

## HOW TO ESTABLISH AND CONNECT TO THE THINGSMASTER CLOUD SERVER

### 1. Download and install VMware Workstation Player.

Please click the link below.

[https://my.vmware.com/en/web/vmware/free#desktop\\_end\\_user\\_computing/vmware\\_workstation\\_player/14\\_0](https://my.vmware.com/en/web/vmware/free#desktop_end_user_computing/vmware_workstation_player/14_0)

### 2. Download the server file from the link that sent by the Sales.


### 3. Open a Virtual Machine from disk and import.

**Note:** Ignore the warning message, check "Do not show this message again" then click Retry.

### 4. Configure network adapter of ThingsMaster VM to make sure that the laptop or the computer can ping the Virtual Machine.

- Go to Player -> Managed -> Virtual Machine Settings
- Choose the Network Adapter
- Set the Network Connection to Bridged
- Click Configure Adapters
- Select the Network Card that user used, user may choose either Wireless or Ethernet connection.

**Note:** User should only enable the NIC which under the same network with the device.



### 5. Start the Virtual Machine, wait till the starting process is done then the ThingsMaster is established.

```

System information as of Fri Aug 17 01:26:35 CST 2018

System load: 0.62          Memory usage: 9%          Processes:   196
Usage of /:  54.9% of 8.73GB  Swap usage:  0%          Users logged in: 0

Graph this data and manage this system at:
https://landscape.canonical.com/

179 packages can be updated.
126 updates are security updates.


user@ubuntu:~$ UIC media player 2.2.0 Weatheruax (revision 2.2.7-14-g3cc1d0c9)
[0000000014c7348] core interface error: no suitable interface module
[000000001426118] core libvlc error: interface "globalhotkeys:none" initialization failed
[0000000014c7348] dummy interface: using the dummy interface module...
[00007f46fc0009b8] core input error: ES_OUT_SET_GROUP_PCR is called too late (pts_delay increased
to 300 ms)
[00007f46fc0009b8] core input error: ES_OUT_RESET_PCR called
[00007f46fc0009b8] core input error: ES_OUT_SET_GROUP_PCR is called too late (pts_delay increased
to 303 ms)
[00007f46fc0009b8] core input error: ES_OUT_RESET_PCR called
[00007f46fc0009b8] core input error: ES_OUT_SET_GROUP_PCR is called too late (pts_delay increased
to 309 ms)
[00007f46fc0009b8] core input error: ES_OUT_RESET_PCR called
[00007f46fc0009b8] core input error: ES_OUT_SET_GROUP_PCR is called too late (pts_delay increased
to 547 ms)
[00007f46fc0009b8] core input error: ES_OUT_RESET_PCR called
user@ubuntu:~$ [00007f46fc0009b8] core input error: ES_OUT_SET_GROUP_PCR is called too late (pts_
delay increased to 637 ms)
[00007f46fc0009b8] core input error: ES_OUT_RESET_PCR called
[00007f46fc0009b8] core input error: ES_OUT_SET_GROUP_PCR is called too late (pts_delay increased
to 719 ms)
[00007f46fc0009b8] core input error: ES_OUT_RESET_PCR called
user@ubuntu:~$ _

```

**6. Open a web browser to Login to Webmin by SSL in order to change some VM configurations.**

Default: <https://192.168.10.101:10000>


User Name/Password: user/user



**7. Configure the IP address and Gateway (optional).** Select 'eth0' to change IP address and add default gateway if needed.

**8. Configure Date & Time of the ThingsMaster Virtual Machine.**

Please adjust the time and change time zone of the VM first. User can configure it from the Webmin interface. Go to Hardware -> System Time -> Set Time -> Change Time Zone



**9. Adjust the time setting by using NTP**

ThingsMaster server has already enabled NTP service; user can synchronize the system time of the device by using NTP.

- Enable the NTP Client from the Web GUI -> choose the Manual IP -> enter the server IP Address (192.168.10.101)

**Date and Time**

**Current Time** Yr 2018 Mon 8 Day 8 Hr 11 Mn 29 Sec 31

**Get PC Time**

**Time Zone** (GMT+08:00)Taipei

**NTP**  Enable NTP client update

**NTP server** time.google.com - Google Public NTP

**Manual IP** 192.168.10.101

**Submit** **Cancel**

**10. Enable WoM IoT service and get connected to the ThingsMaster.**

System  
Ethernet Port  
PoE  
QoS  
Multicast  
Redundancy  
Serial  
GPS  
Security  
Warning  
Diagnostics  
**IoT** ➔  
Backup/Restore  
Firmware Upgrade  
Reset to Default

AWS IoT   Azure IoT   **WoM IoT**   Modbus Device

**WoM IoT**

**Enable**

**IoT Server** 192.168.10.101


**Client ID** scb1200abc

**MQTT Publish Topic** mqtt/demo2

**Submit** **Cancel**

**3.11.4 CoAP**

This page allows the user to configure the CoAP (Constrained Application Protocol) server settings.



The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enable</b>	Check the box to enable the function.
<b>Last Status</b>	Shows the results of last update to CoAP server
<b>COAP URI</b>	Specify the URI ( <b>U</b> niform <b>R</b> esource <b>L</b> ocator) address of CoAP server. The figure above show example configuration in WebGUI & NodeRed.
<b>Method</b>	Support "POST" method. Other methods can be supported by request.
<b>Publish Interval</b>	<b>Default: 10 (Seconds)</b> Specify the interval (in seconds) between each upload
<b>Debug Mode</b>	Check to enable debug mode for CoAP connection.
<b>Debug Log</b>	Download log for problem analysis between device and CoAP server

The following shows example of CoAP payload. Contact WoMaster salesperson for customized payload.

**CoAP payload:**

```
{ "modelName": "WR222-WLAN+LTE", "devicename": "router", "version": "1.1.1", "mac address": "94:66:e7:00:24:be", "serial number": "N/A", "IPADD": "192.168.10.22", "status": "normal" , "latitude": "25.034", "longitude": "121.5641" , "act": 2, "rssi": -75, "rscp": -79, "ecio": -12 , "di1": "0" , "lte_rx": 0.00 , "lte_tx": 0.00 , "lte_bytes": 0, "CO2": 1, "Temperature": 2}
```

CoAP content-format: application/json

**Key-value format:**

Key is always a string, while value can be either string, Boolean, double or long.

```
{"stringKey": "String1", "booleanKey": true, "doubleKey": 10.0, "longKey": 20}
```

### 3.11.4 Modbus Device

This page allows the user to configure the Modbus connection, so that the device will be connected to the device. Any kind of sensor should have their own information please check their information.

#### MODBUS Logging

**Modbus Logging**  Enable

**Name**

**Slave ID**

**Address**


**Function**

**Data Type**

#### Modbus RTU Slave Tag List

Select	Name	Slave ID	Address	Function Code	Data Type	Edit
<input type="checkbox"/>	CO2	1	562	03	uint32	<input type="button" value="Edit"/>
<input type="checkbox"/>	Temperature	1	564	03	uint32	<input type="button" value="Edit"/>
<input type="checkbox"/>	Humidity	1	566	03	uint32	<input type="button" value="Edit"/>

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Modbus Logging</b>	Check the box to enable the function.
<b>Name</b>	Enter the Modbus name
<b>Slave ID</b>	Enter the Slave ID that belongs to the device
<b>Address</b>	Enter the address that belongs to the device.
<b>Function</b>	<p><b>Function</b></p> 
<b>Data Type</b>	<p><b>Default: Uint32</b></p> <p>Select the Data Type</p>
<b>Alive</b>	The Alive status of the target Protocol/PLC address of the connected sensor.
<b>Value</b>	The Value of the target Protocol/PLC address the router read from the sensor.

### 3.11.5 RMS/OTA

This page allows the user to configure the RMS (Remote Management System) server. The page is used only for

Home > IoT > RMS

AWS IoT | Azure IoT | Private IoT | COAP | Modbus Device | **RMS**

### Remote Management System

**Enable**

**Status** OK

**Protocol**  COAP  MQTT

**RMS Server** 192.168.0.21

**COAP Port** 5683

**ACCESS TOKEN** COAP\_WR222

**Publish Interval** 10 seconds

**CA Certificate** Choose File No file chosen **Import**

**Debug Mode**

**Debug Log** **Download**

**Submit** **Cancel** **Reload**

The description of the columns is as below:

TERMS	DESCRIPTION
<b>Enable</b>	Check the box to enable the RMS function.
<b>Status</b>	Show the connection status between device and RMS server
<b>Protocol</b>	Select protocol for uploaded payload. CoAP and MQTT are supported. Contact WoMaster salesperson for other protocols.
<b>RMS Server</b>	Enter the RMS Server IP Address
<b>CoAP Port</b>	Specify connection port of selected upload protocol.
<b>ACCESS TOKEN</b>	Generate the token from ThingsMaster RMS; this access token is used to access the device by ThingsMaster Cloud.
<b>Publish Interval</b>	<b>Default: 10 (Seconds)</b> Specify the interval (in seconds) between each upload.
<b>CA Certificate</b>	The function from this certificate file is to create an encrypted MQTT communication. User will get this file when download the ThingsMaster server file. <b>Note. This field only supports in ThingsMaster OTA v1.0.0 and later version.</b>
<b>Debug Mode</b>	Check to enable debug mode for CoAP connection.
<b>Debug Log</b>	Download log for problem analysis between device and CoAP server


Click Submit to apply the configuration. After succeeding with the registration then the device will appear on the ThingsMaster RMS dashboard.

## HOW TO ESTABLISH AND CONNECT TO THE THINGSMASTER RMS SERVER


1. Contact our Sales to get the access to the ThingsMaster RMS Account.
2. Login to ThingsMaster RMS, using RMS Account.

**Login:** <User RMS Account>


**Password:** <User RMS Password>



3. Go to Home -> Device Management to register the device.



4. Add new device information, by clicking the "+" at the corner of the page.




After click “+” menu then a page will pop up. Enter the device information.

- Name: Please start the name with Router + Number.
- Device type: default
- Is gateway: check the box
- Click **Add**


The image shows a modal window titled 'Add Device'. It contains the following fields and controls:

- Name\*: Router5
- Device type\*: default
- Is gateway
- Description: (empty text area)
- Buttons: ADD and CANCEL


5. After the device is registered, then click on the device folder go to Details -> Click on Copy Access Token. This access token is code to link the device with the RMS Server.



6. Go to the Web GUI -> IoT -> RMS. Paste the Access Token code to the Web GUI. And complete the configuration.




7. After the configuration is done then go back to ThingsMaster RMS Server. And then click on the newly added Router -> Attributes-> Client Attributes to see if the data has been uploaded.



<input type="checkbox"/>	Last update time	Key ↑	Value
<input type="checkbox"/>	2018-08-29 19:30:44	devicename	router
<input type="checkbox"/>	2018-08-29 19:30:44	latitude	53.2734
<input type="checkbox"/>	2018-08-29 19:30:44	longitude	-7.77832031
<input type="checkbox"/>	2018-08-29 19:30:44	mac address	94:66:e7:29:29:29
<input type="checkbox"/>	2018-08-29 19:30:44	modelname	WA329P
<input type="checkbox"/>	2018-08-29 19:30:44	rssi	-1
<input type="checkbox"/>	2018-08-29 19:30:44	version	beta-08291739

8. If all of the data has been uploaded, user can create a dashboard to visualize the data. Go to Dashboards menu. In this page, user can upload the JSON file that sent by the WoMaster Sales in the email. Click the “+” to import JSON File or Create a new Dashboard.



9. After the JSON file is uploaded, the dashboard will show as below:

### Entities

Entity name	Entity type	RSSI	Modelname	Device Name	Mac Address	Version	Active	lastConnect
SCB1200	Device	-59	SCB1200	router	94:66:e7:9f:00:02	vbeta-09101653	true	5:43:06 PM
WR322	Device	-109	BORM04GR-WLAN-LTE-E	router	94:66:e7:ff:31:12	v1.102	false	6:26:34 PM

Page: 1 Rows per page: 10 1 - 3 of 3

### RSSI History


avg -66.63

### Device Google Maps

### Bus Route Map

## 3.12 BACKUP AND RESTORE

User can use WoMaster's Backup and Restore configuration to save and load configuration through the router. There are 2 modes for users to backup/restore the configuration file.



The screenshot shows the 'WEB Backup and Restore' interface. At the top, there are two tabs: 'WEB' (selected) and 'USB'. Below the tabs, the title 'WEB Backup and Restore' is displayed. Underneath, there is a link 'Restore Settings From File' and a file selection area with a 'Choose File' button and the text 'No file chosen'. At the bottom, there are two blue buttons: 'Restore' and 'Download Backup'.

**Web** mode: In this mode, the router acts as the file server. Users can browse the target folder and then type the file name to back-up the configuration. Browse the target folder and select existed configuration file to restore the configuration back to the router. This mode is only provided by Web UI while CLI is not supported. Also, this feature provides the Download Backup button in order to download the backup configuration from the router.



The screenshot shows the 'USB Backup and Restore' interface. At the top, there are two tabs: 'WEB' and 'USB' (selected). Below the tabs, the title 'USB Backup and Restore' is displayed. Underneath, there are two sections. The first section is 'Load from USB' with a text input field containing 'Example:router.conf' and a blue 'Restore' button below it. The second section is 'Save to USB' with a text input field containing 'Example:router.conf' and a blue 'Backup' button below it.


**USB** mode: this mode has two functions, Load Setting from File and Save Setting to USB. Load Setting from File, make sure that the USB has been inserted and it has the *.conf* file which is the backup files. After inserting the USB, the USB port will directly read the USB and then user needs to type the specific filename. Then click **Restore**. At the Save Setting to USB part, all of the configuration settings would be saved to the USB, with *.conf* as the file type by clicking the **Backup** button.

### 3.13 FIRMWARE UPGRADE

WoMaster provides the latest firmware online at [www.womaster.eu](http://www.womaster.eu). The new firmware may include new features, bug fixes or other software changes. WoMaster also provides the release notes for the update as well. For technical viewpoint, WoMaster suggests user uses the latest firmware before installing the router to the customer site.

**NOTE:** Note that the system will be automatically rebooted after User finished upgrading the new firmware. Please remind the attached network users before User performs this function.

There are 2 modes for users to backup/restore the configuration file, Web mode, and USB mode.



The screenshot shows the 'WEB Firmware Upgrade' interface. At the top, there are two tabs: 'WEB' (selected) and 'USB'. Below the tabs, the title 'WEB Firmware Upgrade' is displayed. Underneath, there is a 'Select File' label followed by a 'Choose File' button and the text 'No file chosen'. At the bottom of the interface, there are two buttons: 'Upgrade' and 'Cancel'.

**Web** mode: The router acts as the file server. Users can browse the target folder and then type the file name to back-up the configuration. Users also can browse the target folder and select the existed upgrade file. This mode is only provided by Web UI while CLI is not supported.




The screenshot shows the 'USB Firmware Upgrade' interface. At the top, there are two tabs: 'WEB' and 'USB' (selected). Below the tabs, the title 'USB Firmware Upgrade' is displayed. Underneath, there is a 'File name' label followed by an empty text input field. At the bottom of the interface, there are two buttons: 'Upgrade' and 'Cancel'.


**USB** mode: plugged the USB device with the firmware file, then type the specific filename of the new firmware file. Then click **Upgrade**.

### 3.14 RESET TO DEFAULTS


This function provides users with a quick way of restoring the WoMaster router's configuration to factory defaults. By check the Restore Factory default IP setting, it means the IP of the device will directly change to the default IP (192.168.10.1).



Pop-up message screen to show User that have done the command. Click on **OK** to close the screen and reboot the device.




Below is the interface for resetting the device with keep the IP Settings.




### 3.15 SAVE

**Save** option allows user to save any configuration. Powering off the router without clicking on **Save** will cause loss of new settings. After selecting **Save**, click on **Yes** to save new configuration.



### 3.16 LOGOUT

There are 2 logout methods. If user doesn't input any command within 30 seconds, the web connection will be logged out. The Logout command allows user to manually logout the web connection. Click on **Yes** to logout.



### 3.17 REBOOT

System Reboot allows user to reboot the device. Some of the feature changes require user to reboot the system. Click on **Reboot** to reboot device.

**NOTE:** Remember to click on Save button to save configuration settings. Otherwise, the settings user made will be gone when the router is powered off.

Reboot main screen, to do confirmation request. Click **Yes**, then the router will reboot immediately.



### 3.18 WOMASTER MIB

WoMaster supports partial Public MIB and also provides Private MIBs for users to **monitor** the device's status by SNMP. The Private MIB can be found in or downloaded from WoMaster Web site ([www.womaster.eu](http://www.womaster.eu)). Compile the private MIB file by SNMP tool or using WoMaster NMS, NetMaster.

Below is the Public MIB for the WoMaster Router products:

- **Bridge-MIB (RFC1493)**
- **Entity MIB (RFC4133)**
- **MIB-II (RFC1213)**

The table below is the Private MIBs and the supported model:

<ul style="list-style-type: none"><li>● WOMASTER-SWITCH-MIB</li><li>● WOMASTER-POE-MIB</li></ul>	DP310/DS310 DP612/DS612 DS409 DP412/DS412 MP310 MP614
<ul style="list-style-type: none"><li>● WOMASTER-ROUTER-MIB</li><li>● WOMASTER-SERIAL-MIB (by Hardware)</li><li>● WOMASTER-CELLULAR-MIB (by Hardware)</li><li>● WOMASTER-GPS-MIB (by Hardware)</li></ul>	SCB1000/SCB1200 WR312/WR322 WR316 DS306 WR329

## 4. REVISION HISTORY

Version	Description	Date	Editor
Draft 1	1 <sup>st</sup> draft version, modify from WR3x2GR UM, update the Hardware description of the WR315GR-2C.	2022/11/22	Orwell
Draft 2	2 <sup>nd</sup> draft version, update SW functions and web GUI.	2022/11/23	Orwell
	-		
	-		
	-		
	-		

## APPENDIX

### ENTITY MIB (RFC4133)

Object Group Name		Object Identifier	Access	Value
entPhysicalTable		1.3.6.1.2.1.47.1.1.1		
	entPhysicalIndex	1.3.6.1.2.1.47.1.1.1.1	Not-accessible	
	entPhysicalDescr	1.3.6.1.2.1.47.1.1.1.2	Read Only	Industrial Secure Cellular Router, 2GbE+2COM, 802.11ac/n WLAN, LTE-E, RSIM, GPS, FDD B1/3/5/7/8/20, TDD B38/40/41
	entPhysicalVendorType	1.3.6.1.2.1.47.1.1.1.3	Read Only	1.3.6.1.4.1.47114.1.1
	entPhysicalContainedIn	1.3.6.1.2.1.47.1.1.1.4	Read Only	0
	entPhysicalClass	1.3.6.1.2.1.47.1.1.1.5	Read Only	other(1)
	entPhysicalParentRelPos	1.3.6.1.2.1.47.1.1.1.6	Read Only	0
	entPhysicalName	1.3.6.1.2.1.47.1.1.1.7	Read Only	router
	entPhysicalHardwareRev	1.3.6.1.2.1.47.1.1.1.8	Read Only	v1.0
	entPhysicalFirmwareRev	1.3.6.1.2.1.47.1.1.1.9	Read Only	v1.2.3
	entPhysicalSoftwareRev	1.3.6.1.2.1.47.1.1.1.10	Read Only	v1.2.3
	entPhysicalMfgName	1.3.6.1.2.1.47.1.1.1.12	Read Only	WoMaster
	entPhysicalModelName	1.3.6.1.2.1.47.1.1.1.13	Read Only	WR322G-WLAN+LTE-E
	entPhysicalIsFRU	1.3.6.1.2.1.47.1.1.1.16	Read Only	False(2)
	entPhysicalMfgDate	1.3.6.1.2.1.47.1.1.1.17	Read Only	
entLastChangeTime		1.3.6.1.2.1.47.1.4.1	Read Only	

### MIB-II (RFC1213)

Object Group Name		Object Identifier	Access	Value
System				
	sysDescr	1.3.6.1.2.1.1.1	Read Only	Industrial Secure Cellular Router, 2GbE+2COM, 802.11ac/n WLAN, LTE-E, GPS, 2SIM, FDD B1/3/5/7/8/20, TDD B38/40/41
	sysObjectID	1.3.6.1.2.1.1.2	Read Only	switch
	sysUpTime	1.3.6.1.2.1.1.3	Read Only	5 minutes 22 seconds (32200)
	sysContact	1.3.6.1.2.1.1.4	Read Only	0
	sysName	1.3.6.1.2.1.1.5	Read Only	WR322GR-WLAN+LTE-E
	sysLocation	1.3.6.1.2.1.1.6	Read Only	Unknown
	sysServices	1.3.6.1.2.1.1.7	Read Only	2
at		1.3.6.1.2.1.3		
atTable		1.3.6.1.2.1.3.1		
	atIfIndex	1.3.6.1.2.1.3.1.1	Read Only	8
	atPhysAddress	1.3.6.1.2.1.3.1.2	Read Only	00-99-99-99-99-99
	atNetAddress	1.3.6.1.2.1.3.1.3	Read Only	192.168.10.2